

Quality, Design and Innovation





# LIEBHERR

<b>1</b> 1.1				
	Scope of delivery	<b>3</b> 5	IceMaker water supply	18
1.2 1.3 1.4	SmartDevice	4 6	TubeClean	19
1.5 <b>2</b>	Conformity	4	CleaningMode	19
3	Functionality of the Touch & Swipe display	6	Display brightness	19
3.1 3.2 3.3	Menus	6 7	Door alarm	20
<b>4</b> 4.1	Switching on appliance (first use)	7 × (h	Input lock	20
4.2 4.3	Starting the HydroBreeze for the first time		Language	20
<b>5</b> 5.1 5.2	Information regarding storage	Service No: Model Index: Securit:	Device information	21
5.3 5.4 5.5	Freezer compartment	8 (15%: 1333)XXXX (15%: 1333)XXX (15%: 1333)XX	Software	21
<b>6</b>	Saving energy 10	2	Reminder	21
<b>7</b> 7.1 7.1.1	Controls 10 Controls and displays 10 Status display. 10		Demo mode	21
7.1.2 7.2	Display symbols		Resetting to factory settings	22
7.2.1	Notes on the appliance functionslı Turn off appliancelı		Fault messages	
	0.1111111111111111111111111111111111111	7.3.2	Message	
7.2.3	Switching temperature zones off and on1 WiFi1		Features  Door rack	
•	Tamanamakuma	8.2	Shelves	
	IDMNOTATIFO	2 83	Dividing shelf	74
5 °c	Temperature1	8.4	Dividing shelf	24
5 ⁻c ℃∕	Temperature unit	8.4 8.5	Space for baking tray Adjustable bottle shelf Drawers	24 25 25
5 <sup>-</sup> , ℃⁄F	Temperature unit1	8.4 8.5 8.6 8.7	Space for baking tray Adjustable bottle shelf Drawers Fruit & Vegetable safe cover	24 25 25 27
°C/ <sub>F</sub>		8.4 8.5 8.6 8.7	Space for baking tray Adjustable bottle shelf Drawers	24 25 25 27
°¢ <sub>€</sub> B5	Temperature unit	8.4 8.5 8.6 8.7 8.8 8.9 8.10	Space for baking tray Adjustable bottle shelf Drawers Fruit & Vegetable safe cover Adjusting the moisture levels HydroBreeze Glass shelves	24 25 25 27 27 27 28
°¢ <sub>€</sub> B5	Temperature unit1	8.4 8.5 3 8.6 8.7 3 8.8 8.9 8.10 3 8.11	Space for baking tray Adjustable bottle shelf Drawers Fruit & Vegetable safe cover Adjusting the moisture levels HydroBreeze Glass shelves IceMaker	24 25 25 27 27 27 28 28
%F B5 D1	Temperature unit	8.4 8.5 3 8.6 8.7 3 8.8 8.9 8.10 3 8.11 8.12 3 8.13	Space for baking tray	24 25 25 27 27 27 28 28 29 29
%F B5 D1	Temperature unit	8.4 8.5 8.6 8.7 3 8.8 8.9 8.10 3 8.11 8.12 3 8.13 8.14	Space for baking tray	24 25 25 27 27 27 28 28 29 29
% B5 D1 *	Temperature unit	8.4 8.5 8.6 8.7 3 8.8 8.9 8.10 3 8.11 8.12 3 8.13 8.14 8.15	Space for baking tray	24 25 25 27 27 27 28 28 29 29 29
% B5 D1 *	Temperature unit	8.4 8.5 3 8.6 8.7 3 8.8 8.9 8.10 3 8.11 8.12 3 8.13 8.14 8.15	Space for baking tray	24 25 25 27 27 27 28 28 29 29 30
%F B5 D1	Temperature unit	8.4 8.5 8.6 8.7 3 8.8 8.9 8.10 8.11 8.12 8.13 8.14 8.15 3 8.16 8.17 8.18	Space for baking tray	24 25 27 27 27 28 28 29 29 29 30 30
% B5 D1 *	Temperature unit	8.4 8.5 8.6 8.7 3 8.8 8.9 8.10 3 8.11 8.12 3 8.13 8.14 8.15 3 8.16 8.17 8.18	Space for baking tray	24 25 27 27 27 28 28 29 29 30 30 31
% B5 D1 *	Temperature unit	8.4 8.5 8.6 8.7 3 8.8 8.9 8.10 3 8.11 8.12 3 8.13 8.14 8.15 3 8.14 8.15 4 9.1 9.2	Space for baking tray	24 25 25 27 27 28 29 29 30 30 31 31
%F B5 D1 ***	Temperature unit	8.4 8.5 8.6 8.7 3 8.8 8.9 8.10 3 8.11 8.12 3 8.13 8.14 8.15 3 8.14 9 9.1 9.2 9.3	Space for baking tray Adjustable bottle shelf Drawers Fruit & Vegetable safe cover Adjusting the moisture levels HydroBreeze Glass shelves IceMaker VarioSpace Butter dish Egg rack Bottle holder FlexSystem Freezer pack Flexible ice compartment divider  Maintenance FreshAir carbon filter Disassembling / assembling pull-out systems Defrosting the appliance Cleaning the appliance	24 25 25 27 27 28 29 29 30 30 31 31 32 32
%**  **\  **\  **\  **\  **\  **\  **\	Temperature unit	8.4 8.5 8.6 8.7 3 8.8 8.9 8.10 3 8.11 8.12 3 8.13 8.14 8.15 3 8.16 8.17 4 9.1 9.2 9.3 9.4 10	Space for baking tray	24 25 25 27 27 28 28 29 29 30 31 31 32 32 33
%F B5 D1  ***  **  **  **  **  **  **  **  **	Temperature unit	8.4 8.5 8.6 8.7 3.8.8 8.9 8.10 3.8.11 8.12 3.8.14 8.15 3.8.14 8.15 4.9 9.1 9.2 9.3 9.4 10.1 10.2 10.3 10.4	Space for baking tray Adjustable bottle shelf Drawers Fruit & Vegetable safe cover Adjusting the moisture levels HydroBreeze Glass shelves IceMaker VarioSpace Butter dish Egg rack Bottle holder FlexSystem Freezer pack Flexible ice compartment divider  Maintenance FreshAir carbon filter Disassembling / assembling pull-out systems Defrosting the appliance Cleaning the appliance  Customer help Technical specifications Operating noises Technical fault Customer Service	24 25 25 27 27 28 29 29 30 31 31 32 32 33 33 33 34 35
%**  **\  **\  **\  **\  **\  **\  **\	Temperature unit	8.4 8.5 8.6 8.7 3.8.8 8.9 8.10 8.11 8.12 8.13 8.14 8.15 8.16 8.17 4.91 9.2 9.3 9.4 10.1 10.2 10.3 10.4 10.5	Space for baking tray Adjustable bottle shelf Drawers Fruit & Vegetable safe cover Adjusting the moisture levels HydroBreeze Glass shelves IceMaker VarioSpace Butter dish Egg rack Bottle holder FlexSystem Freezer pack Flexible ice compartment divider  Maintenance FreshAir carbon filter Disassembling / assembling pull-out systems Defrosting the appliance Cleaning the appliance Customer help Technical specifications Operating noises Technical fault	24 25 25 27 28 29 29 30 30 31 31 32 32 33 33 33 33 33 35 35

#### 12.2 Disposing of the appliance in an environmentally friendly manner.....

The manufacturer is continually working on the further development of all types and models. Please be aware that we reserve the right to make changes to the shape, equip-

# ment and technology. Symbol

#### Explanation

#### **Read instructions** Please read the information in these instructions carefully to understand all of the benefits



#### Full instructions on the internet

of your new appliance.

You can find detailed instructions on the internet using the QR code on the front of these instruction or by entering the service number at home.liebherr.com/fridge-

The service number can be found on the serial tag:




Fig. Example illustration



#### Check appliance

Check all parts for transport damage. If you have any complaints, please contact your agent or customer service.



#### **Differences**

These instructions apply to a range of models, so differences are possible. Sections that apply to certain models only are marked with an asterisk (\*).



#### Instructions and results

Instructions are marked with a . Results are marked with a  $\triangleright$ .



#### Videos

Videos about the appliances are available on the YouTube channels of Liebherr-Hausgeräte.

These operating instructions apply to:

ICBNh 5173

If your appliance has an N in its appliance designation, it is a NoFrost appliance.

# 1 Appliance at a glance

# 1.1 Scope of delivery

Check all parts for transport damage. Contact your dealer or customer service in the event of complaints. (see 10.4 Customer Service)

Your new appliance comes with the following parts:

- Built-in appliance
- Features (depending on the model)

- Installation materials (depending on the model)
- "Quick Start Guide"
- "Installation Guide"

# 1.2 Overview of the appliance and equipment




Fig. 1 Example illustration

#### Temperature range

(A) Fridge section (C) Freezer section (D) Coldest area (B) BioFresh

#### Equipment

- (1) Controls
- (2) Fan with FreshAir activated charcoal filter
- (3) Dry rear wall
- (4) Divisible shelf
- (5) Shelf
- (6) Space for baking tray
- (7) Variable bottle rack
- (8) Lid for Fruit & Vegetable-Safe
- (9) HydroBreeze
- (10) Fruit & Vegetable-Safe

- (11) Drain opening
- (12) Meat & Dairy-Safe
- (13) Freezer drawer
- (14) IceMaker
- (15) VarioSpace
- (16) Type plate
- (17) Door racks
- (18) Bottle holder
- (19) VarioBoxes
- (20) Closing damper

► Shelves, drawers and baskets are arranged for optimum energy efficiency when the appliance is delivered. Changing how the shelves, for example, are inserted in the fridge compartment does not have any impact on energy consumption.

# **General safety instructions**

#### 1.3 SmartDevice

SmartDevice is the networking solution for your fridge-

If your appliance SmartDevice-enabled or compatible, you can quickly and easily connect your appliance to your WiFi. With the SmartDevice app, you can operate your appliance from a mobile device. Additional functions and setting options are available in the SmartDevice SmartDevice app.

SmartDeviceance:

Your appliance is compatible for use compatible appli- with the SmartDeviceBox. You must first purchase and install the Smart-DeviceBox. In order to connect your appliance to the WiFi, you need to download the SmartDevice app.



about SmartDevice:

information smartdevice.liebherr.com

Purchasing SmartDeviceBox in the Liebherr-Hausgeräte store:

the home.liebherr.com/shop/de/deu/ smartdevicebox.html

Downloading the SmartDevice app:



After installing and configuring the SmartDevice, you can connect your appliance to the WiFi using the SmartDevice app and the WiFi appliance function (see WiFi).

#### Note

The SmartDevice function is not available in the following countries: Russia, Belarus, Kazakhstan.

You cannot use the SmartDeviceBox.

# 1.4 Appliance range of use

#### Intended use

The appliance is only suitable for cooling food products in a domestic or household-like environment. This includes, for example, use:

- in staff kitchens, bed and breakfast establishments.
- by guests in country houses, hotels, motels and other accommodation.
- for catering and similar services in the wholesale trade.

All other types of use are not permitted.

#### Foreseeable misuse

The following applications are expressly forbidden:

- Storing and refrigerating medicines, blood plasma, laboratory preparations or similar

- substances and products based on the Medical Device Directive 2007/47/EC
- Use in outdoor areas with very high humidity
- Use in areas at risk of explosions

Misusing the appliance may lead to damage to the goods stored or they may spoil.

#### Climate classifications

Depending on the climate classification the appliance is designed to operate in restricted ambient temperatures. The climate classification applying to your appliance is printed on the rating plate.

#### Note

► Keep to the specified ambient temperatures in order to guarantee that the appliance works properly.

Climate classification	for ambient temperatures of
SN	10 °C to 32 °C
N	16 °C to 32 °C
ST	16 °C to 38 °C
Т	16 °C to 43 °C
SN-ST	10 °C to 38 °C
SN-T	10 °C to 43 °C

# 1.5 Conformity

The refrigerant circuit has been tested for leaks. When installed, the appliance complies with the applicable safety regulations and with the corresponding directives.

The full text of the EU Declaration of Conformity is available on the following website: www.Liebherr.com

The BioFresh compartment meets the requirements of a cold storage compartment as set out in DIN EN 62552:2020.

# 2 General safety instructions

Please keep these instructions in a safe place and pass them on to any subsequent owners. Read these operating instructions carefully before use to ensure safe and correct use of the appliance. Follow the instructions, safety instructions and warning messages included at all times. They are important for ensuring you can operate and install the appliance safely and without any problems.

#### Danger for the user:

- This device can be used by children and people with impaired physical, sensory or mental abilities or with a lack of experience and knowledge provided that they are supervised or have received instruction in the safe use of this device, and about the resulting hazards. Children must not play with this appliance. Cleaning and user maintenance work must not be carried out by children without adult supervision. Children aged between 3 and 8 are allowed to load and unload the appliance. Children below the age of 3 must be kept away from the appliance unless they are under continuous adult supervision.

- The socket must be easily accessible so that the appliance can be disconnected quickly from the electricity in an emergency. It must not be located in the area behind the appliance.
- When disconnecting the appliance from the supply, always take hold of the plug. Do not pull the cable.
- In the event of a fault pull out the mains plug or deactivate the fuse.
- Do not damage the mains power cable. Do not operate the appliance with a defective mains power cable.
- If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.
- Only customer service or other specially trained staff may repair or perform other operations on the appliance.
- Only install, connect and dispose of the appliance according to the instructions.
- Only use the appliance when is installed.
- Special lights, such as LED lights on the appliance, are used to illuminate the interior of the appliance and are not suitable for room lighting.
- The manufacturer is not liable for damage caused by a faulty fixed water connection.

#### Fire hazard:

- This appliance contains a refrigerant which is environmentally friendly, but flammable. Leaking refrigerant may ignite. It is hazardous for anyone other than an Authorised Service Person to service this appliance. In Queensland, the authorised Service Person MUST hold a Gas Work Authorisation for hydrocarbon refrigerants, to carry out Servicing or repairs where the gas system is being opened or charged.
- The coolant used (information on the model plate) is ecofriendly but also flammable. Any leaking coolant may ignite.
  - Do not damage the refrigerant circuit pipes.
  - Do not handle ignition sources inside the appliance.

- Do not use electrical appliances inside the appliance (e.g. steam cleaners, heaters, ice cream makers, etc.).
- If the refrigerant leaks: remove any naked flames or ignition sources from the vicinity of the leakage point. Properly air the room. Inform customer services.
- Do not store explosives or sprays using combustible propellants such as butane, propane, pentane, etc. in the appliance. To identify these spray cans, look for the list of contents printed on the can, or a flame symbol. Gases possibly escaping may ignite due to electrical components.
- Keep burning candles, lamps and other items with naked flames away from the appliance so that they do not set the appliance on fire.
- WARNING: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- WARNING: Do not damage the refrigerant circuit.
- Please be sure to store alcoholic drinks or other packaging containing alcohol in tightly closed containers. Any alcohol that leaks out may be ignited by electrical components.

## Danger of tipping and falling:

- Do not misuse the plinth, drawers, doors etc. as a step or for support. This applies particularly to children.

#### Danger of food poisoning:

 Do not consume food which has been stored too long.

#### Danger of frostbite, numbness and pain:

- Avoid prolonged skin contact with cold surfaces or refrigerated/frozen goods or take protective measures, e.g wear gloves.
- Do not consume ice cream, water ice or ice cubes immediately and do not consume them too cold.

# Danger of injury and damage:

- Hot steam can lead to injury. Do not use electrical heating or steam cleaning equipment, open flames or defrosting sprays to defrost.
- Do not use sharp implements to remove the ice.

# Functionality of the Touch & Swipe display

#### Risk of crushing:

- Do not hold the hinge when opening and closing the door. Fingers may get caught.

## Symbols on the appliance:



This symbol may be located on the compressor. It relates to the oil in the compressor and makes reference to the risk that: Swallowing or inhaling can be fatal. This advice is only relevant to recycling. There is no danger in normal operation.



This symbol is located on the compressor and indicates the danger of flammable materials. Do not remove the sticker.



This or a similar sticker may be located on the rear of the appliance. This sticker indicates that there are vacuum insulation panels (VIP) or perlite panels in the door and/or housing. This advice is only relevant to recycling. Do not remove the sticker.

# Please note the warning messages and other specific advice in the other chapters:

<u> </u>	DANGER	indicates an immediately hazardous situation which will lead to death or serious injuries if it is not avoided.
<u> </u>	WARNING	indicates a hazardous situation which may lead to death or serious injuries if it is not avoided.
<u> </u>	CAUTION	indicates a hazardous situation which may lead to minor or moderate injuries if it is not avoided.
	NOTICE	indicates a hazardous situation which may lead to damage to property if it is not avoided.
	Note	indicates useful instructions and tips.

# 3 Functionality of the Touch & Swipe display

You operate your appliance using the Touch & Swipe display. You select appliance functions in the Touch & Swipe display (hereafter referred to as display) by tapping them. If you do not perform any action on the display for 10 seconds, the display either jumps back to the higher-level menu or directly to the status display.

# 3.1 Navigation and symbol explanation

In the illustrations, different symbols are used to navigate the display. The following table describes these symbols.

Symbol	Description
	Briefly touch the display: Activates/deactivates function. Confirms selection. Opens submenu.

Symbol	Description
,	Touch the display for a specified time (e.g. 3 seconds):
(33)	Activates/deactivates function or value.
	Swipe left or right:
	Navigate in the menu.
	Briefly touch the Back symbol:
Back	Jumps back one menu level.
$\langle \gamma \rangle$	Press and hold the Back symbol for 3 seconds:
Back (3s)	Jumps back to the status display.
•	Arrow with clock:
Ó	It takes more than 10 seconds for the following message to appear in the display.
$\rightarrow \rightarrow \rightarrow$	Arrow with a time indication:
2s 5s 10s	It takes the specified amount of time until the following message appears in the display.
	"Open Settings menu" symbol:
={0}	Navigates to the Settings menu and opens the settings menu.
	If necessary: Navigate to the desired function in the Settings menu.
	(see 3.2.1 Opening the Settings menu)
	"Open Advanced menu" symbol:
	Navigates to the Advanced menu and opens the advanced menu.
	If necessary: Navigate to the desired function in the Advanced menu.
	(see 3.2.2 Opening the expanded menu)
No action for 10 seconds	If you do not perform any action on the display for 10 seconds, the display either jumps back to the higher-level menu or directly to the status display.
Open door and close it again.	If you open the door and immediately close it again, the display jumps directly back to the status display.

Note: Illustrations of the display are shown in the English version.

# 3.2 Menus

The appliance functions are distributed over various menus:

Menu	Description	
Main menu	When you switch the appliance on, you are automatically in the main menu.	
	From here you can navigate to the most important appliance functions, to the Settings menu and to the Advanced menu.	
Settings	The Settings menu contains additional appliance functions for setting up your appliance.	
Settings menu		
Advanced menu	The advanced menu contains special appliance functions for setting up your appliance. Access to the Advanced menu is protected by the numerical code <b>151</b> .	

#### 3.2.1 Opening the Settings menu




Fig. 2 Example illustration

- Carry out action steps according to the illustration.
- ▷ Settings menu is open.
- ▶ If necessary: Navigate to the desired function.

#### 3.2.2 Opening the expanded menu



Fig. 3




Fig. 4 Example illustration, access with numerical code **151** 

- ► Carry out action steps according to the illustration.
- > The expanded menu is open.
- ▶ If necessary: Navigate to the desired function.

# 3.3 Sleep mode

If you do not touch the display for 1 minute, the display switches to sleep mode. In sleep mode, the display brightness is dimmed.

#### 3.3.1 Ending sleep mode

- ► Touch the display briefly with your finger.
- Sleep mode is ended.

# 4 Putting into operation

# 4.1 Switching on appliance (first use)

Make sure that the following requirements are fulfilled:

- ☐ The appliance is properly installed and connected according to the installation instructions.
  - ☐ All adhesive strips, adhesive and protective films and transport locks are removed from inside and on the appliance.
  - ☐ All marketing leaflets are removed from the drawers.
- ☐ You are familiar with the functionality of the Touch & Swipe display. (see 3 Functionality of the Touch & Swipe display)

#### Switch on the appliance using the Touch & Swipe display:

- ▶ If the display is in sleep mode: Briefly touch the display.
- ► Carry out action steps according to the illustration.




Fig. 5 Example illustration

- ▷ The status display appears.
- ➤ The appliance cools to the temperature set at the factory.
- ▶ The appliance starts in demo mode (status display with DEMO appears): If the appliance starts in demo mode, you can deactivate demo mode within the next 5 minutes. (see Demo mode)

#### More information:

- Start the IceMaker for the first time. (see 4.2 Starting the IceMaker for the first time)
- Start the HydroBreeze for the first time. (see 4.3 Starting the HydroBreeze for the first time)
- Start the SmartDevice for the first time. (see 1.3 Smart-Device) and (see WiFi)

#### Note

The manufacturer recommends:

- ► Stock with food: Wait for around 6 hours until the set temperature is reached.
- ▶ Store frozen foods at -18 °C or colder.
- ► Observe the notes on storing food. (see 5.1 Information regarding storage)

# Storage

#### Note

Accessories can be purchased from the Liebherr-Hausgeräte home.liebherr.com/shop/de/deu/ store at zubehor.html.

# 4.2 Starting the IceMaker for the first

If your appliance is equipped with IceMaker, you must clean the IceMaker before using it for the first time.

Make sure that the following requirements are fulfilled:

- ☐ The water supply has been connected. See Installation Guide or mounting instructions.
- ☐ The appliance is properly installed and connected.
- ► Clean the IceMaker. (see 9.4.5 Cleaning the IceMaker)

# 4.3 Starting the HydroBreeze for the first time

If your appliance is equipped with HydroBreeze, you must clean the HydroBreeze before using it for the first time.

Make sure that the following requirements are fulfilled:

- ☐ The appliance is properly installed and connected.
- ▶ Clean the HydroBreeze. (see 9.4.4 Cleaning the Hydro-Breeze)
- Fill the water tank. (see 8.9.1 Fill the water tank)
- ► Activate HydroBreeze. (see HydroBreeze)

# 5 Storage

# 5.1 Information regarding storage



# **WARNING**

Risk of fire

Do not use any electrical appliances in the food area of the appliance unless recommended by the manufacturer.

#### Note

The energy consumption increases and the cooling power goes down if ventilation is not sufficient.

► Always keep air slots clear.

Observe the following specifications for storage:

- Keep the air vents on the inside of the rear wall free.
- Keep the air vents on the fan free.\*
- In the freezer compartment: Package food properly.
- Package or cover foods that readily take on or give off odours or taste in closed containers.
- Package raw meat or fish in clean, closed containers. This will prevent meat or fish from touching or dripping onto other food.
- Keep liquids in closed containers.
- Leave space between goods to ensure good air circulation.
- Store food according to the instructions on the packaging.
- Always observe the best-before date indicated on the packaging.

#### Note

Failure to follow these guidelines can lead to foodstuffs spoiling.

# 5.2 Fridge compartment

The air circulation in the appliance creates different temperature zones. You will find the different temperature zones in the appliance and equipment overview. (see 1.2 Overview of the appliance and equipment)

#### 5.2.1 Arranging your food properly

- ▶ Upper area and door: Store butter, cheese, tinned food and tubes.
- Coldest temperature zone: Store perishable foods such as pre-cooked meals.

#### 5.3 BioFresh

BioFresh will extend the storage time for some fresh foods compared to traditional refrigeration.

#### Note

If the temperature drops below 0 °C foods may freeze.

Store cold-sensitive produce such as cucumbers, aubergines, courgettes and tropical fruit in the fridge compart-

## 5.3.1 Fruit & Vegetable safe





This safe creates a storage climate of close to 0 °C. The tight lid ensures constant levels of humidity. This storage climate is suitable for storing unpackaged food with high intrinsic moisture (for example, lettuce, vegetables, fruit).

The humidity in the compartment depends on the moisture content of the chilled goods placed in it, and also depends on how often the compartment is opened. You can regulate the humidity level. (see 8.8 Adjusting the moisture levels)

#### Arranging your food properly

- Store unpackaged fruit and vegetables. If the humidity is too high:
- Regulate the humidity. (see 8.8 Adjusting the moisture

## 5.3.2 Meat & Dairy safe 🙉 🔎 💠





This safe creates a storage climate of close to 0 °C. This storage climate is suitable for more sensitive foods (e.g. dairy products, meat, fish, sausage).

#### Arranging your food properly

► Store dry or packaged food.

# 5.4 Freezer compartment

Here, a dry, frosty storage climate is created at -18 °C. The frosty storage climate is suitable for storing frozen food for several months, for making ice cubes or freezing fresh food.

#### 5.4.1 Freezing food

#### Freezing quantity

The maximum amount of fresh food that you can freeze within 24 hours is specified on the type plate (see 10.5 Model plate) under "Freezing capacity ... kg/24h".

To ensure that food quickly freezes through, adhere to the following quantities per package:

- Fruit and vegetables up to 1 kg
- Meat up to 2.5 kg

#### Freezing food using SuperFrost

Depending on the quantity to be frozen, you can activate SuperFrost before freezing in order to achieve lower freezing temperatures. (see SuperFrost)

► Activate SuperFrost if the amount of food you have to freeze is more than approx. 2 kg.

The time at which you activate SuperFrost depends on the amount of food you have to freeze:

Freezing quantity	Time at which you should activate SuperFrost
Small amount of food to freeze	Activate SuperFrost about 6 hours before freezing.
	You can place the food in the freezer as soon as the appliance automatically deactivates SuperFrost.
Maximum amount of food	Activate SuperFrost about 24 hours before freezing.
to freeze	You can place the food in the freezer as soon as the appliance automatically deactivates SuperFrost.

#### Arranging your food properly



#### **CAUTION**

Risk of injury from broken glass!

Bottles and cans with beverages can burst during freezing. This applies in particular to carbonated beverages.

▶ Only freeze bottles and cans with beverages if you have activated the BottleTimer function in the SmartDevice app.

Freezing quantity	Arranging your food properly		
Small amount of food to freeze	Distribute packaged groceries throughout all drawers.		
	If possible, place groceries at the back of the drawer near the rear wall.		
Maximum amount of food to freeze	Distribute packaged groceries throughout all drawers.		
	If possible, place groceries at the back of the drawer near the rear wall.		

#### 5.4.2 Defrosting food



#### WARNING

Risk of food poisoning!

- ▶ Do not re-freeze thawed food.
- ▶ Use defrosted foodstuff as soon as possible.

You can defrost food in several ways:

- In the fridge compartment
- In the microwave
- In the oven/fan-assisted oven
- At room temperature
- ▶ Take out only as much food as necessary.

#### 5.4.3 Freezer tray

You can freeze berries, herbs, vegetables and other small frozen food in the freezer tray without it all freezing together. The frozen food is less likely to get squashed and subsequent portioning is easier.

In addition, you can store the cold storage accumulators in the freezer tray to save space.

► Distribute food on the freezer tray without packaging and well spaced out.

# 5.5 Storage times

Refer to the specified storage times as a guide.

In the case of foods with a minimum shelf life, the date indicated on the packaging still applies.

#### 5.5.1 Fridge section

Always follow the best-before date stated on the packaging.

#### 5.5.2 BioFresh

Recommended storage periods in the Meat & Dairy-Safe			
Butter	at 1 °C	up to 90 days	
Hard cheese	at 1 °C	up to 110 days	
Milk	at 1 °C	up to 12 days	
Sausage, cold meats	at 1 °C	up to 8 days	
Poultry	at 1 °C	up to 6 days	
Pork	at 1 °C	up to 6 days	
Beef	at 1 °C	up to 6 days	
Game	at 1 °C	up to 6 days	

#### Note

► Remember that high-protein foods perish quicker; shell-fish and crustaceans do not last as long as fish, and fish does not last as long as meat.

Recommended storage periods in the Fruit & Vegetable- Safe				
Vegetables, salads				
Artichokes	at 1 °C	up to 14 days		
Celery	at 1 °C	up to 28 days		
Cauliflower	at 1 °C	up to 21 days		
Broccoli	at 1 °C	up to 13 days		
Chicory	at 1 °C	up to 27 days		
Lettuce	at 1 °C	up to 19 days		
Peas	at 1 °C	up to 14 days		
Kale	at 1 °C	up to 14 days		
Carrots	at 1 °C	up to 80 days		
Garlic	at 1 °C	up to 160 days		
Turnip	at 1 °C	up to 14 days		
Lettuce	at 1 °C	up to 13 days		
Herbs	at 1 °C	up to 13 days		
Leeks	at 1 °C	up to 29 days		
Mushrooms	at 1 °C	up to 7 days		
Radishes	at 1 °C	up to 10 days		
Brussels sprouts	at 1 °C	up to 20 days		
Asparagus	at 1 °C	up to 18 days		
Spinach	at 1 °C	up to 13 days		
Savoy	at 1 °C	up to 20 days		
Fruit				

# Saving energy

Recommended storage periods in the Fruit & Vegetable-Safe			
Apricots	at 1 °C	up to 13 days	
Apples	at 1 °C	up to 80 days	
Pears	at 1 °C	up to 55 days	
Blackberries	at 1 °C	up to 3 days	
Dates	at 1 °C	up to 180 days	
Strawberries	at 1 °C	up to 7 days	
Figs	at 1 °C	up to 7 days	
Blueberries	at 1 °C	up to 9 days	
Raspberries	at 1 °C	up to 3 days	
Currants	at 1 °C	up to 7 days	
Sweet cherries	at 1 °C	up to 14 days	
Kiwis	at 1 °C	up to 80 days	
Peaches	at 1 °C	up to 13 days	
Plums	at 1 °C	up to 20 days	
Cranberries	at 1 °C	up to 60 days	
Rhubarb	at 1 °C	up to 13 days	
Gooseberries	at 1 °C	up to 13 days	
Grapes	at 1 °C	up to 29 days	

#### 5.5.3 Freezer compartment

Recommended storage period for various types of food			
Ice cream	at -18 °C	2 to 6 months	
Sausages, ham	at -18 °C	2 to 3 months	
Bread, baked goods	at -18 °C	2 to 6 months	
Game, pork	at -18 °C	6 to 9 months	
Fatty fish	at -18 °C	2 to 6 months	
Lean fish	at -18 °C	6 to 8 months	
Cheese	at -18 °C	2 to 6 months	
Poultry, beef	at -18 °C	6 to 12 months	
Vegetables, fruit	at -18 °C	6 to 12 months	

# 6 Saving energy

- Pay attention to good ventilation. Do not cover ventilation holes or grids.
- Always keep the fan air slits clear.
- Do not install the appliance in direct sunlight, next to an oven, radiator or similar.
- Energy consumption depends on the installation conditions, e.g. the ambient temperature (see 1.4 Appliance range of use) . A warmer ambient temperature can increase the energy consumption.
- Open the appliance for as short a time as possible.
- The lower the temperature is set the higher the energy consumption.
- Sort your food: home.liebherr.com/food.
- Keep all food properly packed and covered. This prevents frost from forming.
- Only take food out for as long as necessary so that it doesn't warm up too much.
- Inserting warm food: allow to cool down to room temperature first.

- Thaw frozen food in the refrigerator.
- For longer periods of absence, use HolidayMode (see HolidayMode).

# 7 Controls

# 7.1 Controls and displays

# 7.1.1 Status display




Fig. 6

- (1) Temperature display of the fridge section
- (2) Temperature display BioFresh
- (3) Freezer compartment temperature display

The Status display shows the set temperatures and is the home display. From there, you can navigate to the options and settings.

#### 7.1.2 Display symbols

Display symbols provide information on the current appliance status:

Symbol	Appliance status			
$\bigcirc$	<b>Standby</b> The appliance or temperature zone is switched off.			
-18°	Flashing number Appliance is working. Temperature flashes until the set temperature is reached.			
	<b>Flashing symbol</b> Appliance is working. Setting is made.			


# 7.2 Appliance functions

#### 7.2.1 Notes on the appliance functions

The appliance functions are set at the factory so that your appliance is fully functional.

Before you alter, activate or deactivate the device functions, make sure that the following requirements are met:

- ☐ You have read and understood the descriptions of how the display works.
- ☐ You have familiarised yourself with the operating and display elements of your appliance.



This setting turns off the whole appliance.

#### Switching off the entire appliance



Fig. 7




Fig. 8

- Turning off the IceMaker.
- Off: Display goes black.

#### 7.2.3 Switching temperature zones off and on

You can switch temperature zones of the appliance off independently.

Application:

- Cleaning
- Defrosting

#### Switching the fridge compartment off

Make sure that the following requirements are fulfilled:

☐ Refrigerator compartment has been emptied.




Fig. 9 Example illustration

- ► Carry out action steps according to the illustration.
- Refrigerator compartment is switched off.

#### Switching the fridge compartment on




Fig. 10 Example illustration

- Carry out action steps according to the illustration.
- ▶ Refrigerator compartment is switched on.
- > The appliance cools to the last set temperature.



Use this function to connect your appliance to WiFi. You can then operate it via the SmartDevice app on a mobile device. You can also use this function to disconnect or reset the WiFi connection.

To connect your device to WiFi, you need the SmartDeviceBox.

More information on the SmartDevice: (see 1.3 SmartDevice)

#### Note

The SmartDevice function is not available in the following countries: Russia, Belarus, Kazakhstan.

You cannot use the SmartDeviceBox.

#### Establishing the WiFi connection for the first time

Make sure that the following requirements are fulfilled:

- ☐ You have purchased and inserted a SmartDeviceBox. (see 1.3 SmartDevice)
- ☐ You have installed the SmartDevice app (see apps.home.liebherr.com).
- ☐ Registration in the SmartDevice app is completed.



Fig. 11




Fig. 12

- ► Carry out action steps according to the illustration.
- Connection is established.

#### Disconnecting from the WiFi



Fig. 13

# **Controls**




Fig. 14

- ► Carry out action steps according to the illustration.
- ▶ There is no connection.

#### Resetting the WiFi connection



Fig. 15




Fig. 16

- ► Carry out action steps according to the illustration.
- ▶ WiFi connection and other WiFi settings are reset to factory settings.

#### Showing information about the WiFi connection



Fig. 17




Fig. 18

► Carry out action steps according to the illustration.

# 5 Temperature

Use this function to set the temperature.

The temperature depends on the following factors:

- How often the door is opened
- How long the door is open for
- The room temperature of the installation site
- The type, temperature and amount of food

# Temperature zone Recommended setting 5 r ment Fridge compart- 5 °C -18 r ment Freezer compart- -18 °C ment (see Setting the temperature in the BioFresh)

#### Setting the temperature in the fridge compartment




Fig. 19

- ► Carry out action steps according to the illustration.

#### Setting the temperature in the freezer compartment




Fig. 20

- ► Carry out action steps according to the illustration.

#### Setting the temperature in the BioFresh

You can set the temperature using the BioFresh B-Value in the customer menu.



# Temperature unit

Use this function to set the temperature unit. You can set degrees Celsius or degrees Fahrenheit as the temperature

#### Setting the temperature unit



Fig. 21




Fig. 22 Example illustration: Switch from degrees Celsius to degrees Fahrenheit.

- Carry out action steps according to the illustration.
- > The temperature unit is set.

#### BioFresh B-Value

Use this function to set the BioFresh B-Value. With the BioFresh B-Value, you can set BioFresh slightly warmer or colder if necessary due to higher or lower ambient temperatures. The BioFresh B-Value is pre-set to value B5 as delivered. If you change the B-Value, refer to the following table:

Value	Description
B1	Lowest temperature
B1-B4	The temperature can drop below 0 °C which means foods can easily freeze.
B5	Pre-set temperature
В9	Highest temperature

#### Setting the BioFresh B-Value



Fig. 23




Fig. 24 Example illustration: Switch from B5 to B6.

- Carry out action steps according to the illustration.
- > Status display shows target temperature.



#### **D-Value**

The D-Value is pre-set for your appliance and is not permitted to be changed.



# **SuperCool**

This function selects the lowest cooling temperature. This gives you colder storage temperatures.

This function is relevant to the fridge section Fig. 1 (A)

- Cool large amounts of food quickly.

#### Activating/deactivating the function

- ▶ Using the fridge section: activate the function when you add the goods.
- Activating/deactivating.

The function automatically turns off. The appliance goes back to normal mode. The temperature adjusts itself to the set level.



# VarioTemp

This function allows you to use the freezer compartment as an additional cooling zone. You can set the temperature from -2 °C to 14 °C. If you activate this function, it may cause more noise. However, the appliance is still fully functional.

For storage of foodstuff in the freezer compartment with the VarioTemp function activated, Liebherr recommends:

Temperature range	Foodstuff		
4 °C to 9 °C	Cooked foods, cheese, preserves		
0 °C	Packaged fruit and vegetables		
-2 °C	Fresh fish and seafood		
10 °C to 14 °C	Cold-sensitive foodstuffs such as sweet potatoes, pumpkin or exotic fruits, food or drinks that should not be eaten too cold		

## **Activating VarioTemp**

Make sure that the following requirements are fulfilled:

☐ The IceMaker has been cleaned. (see 9.4.5 Cleaning the IceMaker)



#### WARNING

Risk of food poisoning!

- ▶ Do not re-freeze thawed food.
- Use defrosted foodstuff as soon as possible.



Fig. 25

# **Controls**




Fig. 26

- ► Carry out steps according to the illustration.
- ∀arioTemp is activated.
- ▷ VarioTemp is set to the preselected value.
- > The status display does not show the preset temperature until it is reached.

#### Adjusting VarioTemp

Make sure that the following requirements are fulfilled:

☐ The VarioTemp is activated. (see Activating VarioTemp)



Risk of food poisoning!

- ▶ Do not re-freeze thawed food.
- ▶ Use defrosted foodstuff as soon as possible.




Fig. 27 Example illustration: Change VarioTemp from 12 °C to 5 °C for a fridge-freezer combination with BioFresh.

- ► Carry out steps according to the illustration.
- ∇arioTemp is adjusted.
- > The status display does not show the new set temperature until it is reached.

#### **Deactivating VarioTemp**



Fig. 28




Fig. 29

- Carry out steps according to the illustration.
- ∀arioTemp is deactivated.
- > The freezer compartment is cooled to the preset temperature.

# \*\* SuperFrost

This function selects the lowest freezing temperature. This gives you colder storage temperatures.

This function refers to the freezer section Fig. 1 (C).

#### Use:

- For storing more than 2 kg fresh food every day.
- Freezing fresh food quickly to the core.
- Increasing the cold reserves in the stored goods before defrosting the appliance.

#### Activating/deactivating the function

With a small amount to freeze:

- Activate 6 hours before use.
  With a maximum amount to freeze:
- ► Activate 24 hours before use.
- ► Activating/deactivating.

The function automatically turns off. The appliance goes back to normal mode. The temperature adjusts itself to the set level.



# Start defrosting cycle

Use this function to start the automatic defrosting cycle manually if it does not start automatically in the event of a fault.

#### Starting defrosting cycle



Fig. 30




Fig. 31

- ► Carry out action steps according to the illustration.
- Defrosting cycle has started: Icon flashes until defrosting cycle is automatically completed.
- When defrosting cycle is finished: The device continues to run in normal mode.

#### Cancelling defrosting cycle

The defrosting cycle will be stopped automatically. However, you can also cancel the defrosting cycle at any time during the defrosting process:



Fig. 32

- ► Carry out action steps according to the illustration.
- Defrosting cycle is cancelled.
- > The device continues to run in normal mode.



# **PartyMode**

You can use this function to activate or deactivate Party-Mode. PartyMode activates various functions that are useful for a party.

PartyMode activates the following functions:

- SuperCool (see SuperCool)
- SuperFrost (see SuperFrost)
- IceMaker with MaxIce (see IceMaker / MaxIce )

You can adjust all listed functions individually and flexibly. When you deactivate PartyMode, all changes are discarded.

If the function is active, the device operates at higher power. As a result, the device's operating noise may be temporarily louder and energy consumption will increase.

#### **Activating PartyMode**

Make sure that the following requirements are fulfilled:

☐ The IceMaker has been started. (see 4.2 Starting the IceMaker for the first time)



Fig. 33




Fig. 34

- ► Carry out action steps according to the illustration.
- ▶ PartyMode and the associated functions are activated.
- > The temperature display turns blue.
- > The current temperature flashes until the target temperature is reached.

#### **Deactivating PartyMode**

The PartyMode is automatically deactivated after 24 seconds. However, you can also deactivate PartyMode manually at any time:



Fig. 35




Fig. 36

- ► Carry out action steps according to the illustration.
- PartyMode is deactivated.
- ▶ The appliance cools to the temperature set previously: The current temperature flashes until the target temperature is reached.



# HolidayMode

This function minimises the energy consumption during an extended absence. The temperature of the refrigerator compartment is set to 15 °C and this is displayed on the status screen when the temperature has been reached.

The set freezer temperature remains unchanged.

This function refers to the fridge section Fig. 1 (A).

#### Use:

- Save energy if you plan to be away for a while.
- Avoid coming home to bad smells and mould.

#### Activating/deactivating the function

- ▶ Empty everything from the fridge section.
- ► Activating/deactivating.
- On: Fridge temperature is raised.
- > Off: the previously set temperature is restored.



#### SabbathMode

You can use this function to activate or deactivate SabbathMode. If you activate this function, some electronic functions are switched off. As a result, your device meets the religious requirements for Jewish holidays such as Sabbath and complies with STAR-K Kosher certification.

Device status when SabbathMode is active

The status display shows SabbathMode permanently.

All functions on the display are locked except for the **Deactivate SabbathMode function**.

Active functions remain active.

The display remains bright when you close the door.

The interior lighting is deactivated.

Reminders are not implemented. The set time interval stops.

Reminders and warnings are not displayed.

There is no door alarm.

There is no temperature alarm.

The IceMaker is switched off.

The defrosting cycle operates only for the specified time, without considering the device consumption.

After a power failure, the device returns to SabbathMode.

Device status

# **Controls**

#### Note

This appliance has certification from the "Institute for Science and Halacha". (www.machonhalacha.co.il)

You can find a list of STAR-K-certified appliances at www.star-k.org/appliances.

#### **Activating SabbathMode**



#### **WARNING**

Danger of food poisoning from spoiled food!

If you have SabbathMode activated and a power failure occurs, no message appears in the status display about the power failure. Once the power is restored, the appliance continues to operate in SabbathMode. The power failure may mean that food spoils and the consumption of this food could lead to food poisoning.

After a power failure:

Do not consume food that was frozen and has thawed out.



Fig. 37




Fig. 38

- ► Carry out action steps according to the illustration.
- ▷ SabbathMode is activated.
- > The status display shows SabbathMode permanently.

#### **Deactivating SabbathMode**

The SabbathMode is automatically deactivated after 80 hours. However, you can also deactivate SabbathMode manually at any time:



Fia 39

- ► Carry out action steps according to the illustration.
- ▷ SabbathMode is deactivated.



#### **EnergySaver**

You can use this function to activate or deactivate Energy saving mode. If energy saving mode is activated, the energy consumption decreases and the temperature in the device increases. The food remains fresh, but the shelf life is shortened.

Temperature zone	Recommended setting (see Temperature)	Temperature with active EnergySaver	
5 ° Fridge section	5 °C	7 °C	

Temperature zone	Recommended setting (see Temperature)	Temperature with active EnergySaver	
-18°c Freezer section	-18 °C	-16 °C	

**Temperatures** 

#### **Activating EnergySaver**



Fig. 40



Fig. 41

- ► Carry out action steps according to the illustration.
- > Energy saving mode is activated.

#### **Deactivating EnergySaver**



Fig. 42




Fig. 43

- ► Carry out action steps according to the illustration.
- Energy saving mode is deactivated.



#### **HydroBreeze**

You can use this function to activate or deactivate Hydro-Breeze. If you activate the function, HydroBreeze generates a fine, cool mist in BioFresh-safe. This extends the shelf life of unpackaged salad, vegetables and fruit with high intrinsic moisture.

If you activate the function, HydroBreeze activates every 90 minutes for 4 seconds when the door is closed. When you open the door, HydroBreeze activates according to the setting:

Value	Description
1	HydroBreeze is active for 4 seconds when the door is open.
2	HydroBreeze is active for 6 seconds when the door is open.
3	HydroBreeze is active for 8 seconds when the door is open.

Value	Description
Deactivated (pre-setting)	HydroBreeze is deactivated.

HydroBreeze duration when the door is open

#### **Activating HydroBreeze**

#### Note

If you activate HydroBreeze but there is no food in the drawer, condensate forms on the base of the drawer.

▶ Only activate HydroBreeze if you are storing food in the

Make sure that the following requirements are fulfilled:

- ☐ The HydroBreeze is clean. (see 9.4.4 Cleaning the Hydro-
- ☐ The water tank is full. (see 8.9.1 Fill the water tank)

Activate HydroBreeze by selecting a value for the Hydro-Breeze duration:



Fig. 44




Fig. 45 Example illustration: Activate HydroBreeze with value 3.

- ► Carry out action steps according to the illustration.

#### **Deactivating HydroBreeze**



Fig. 46




Fig. 47

- Carry out action steps according to the illustration.
- HydroBreeze is deactivated.



# IceMaker / MaxIce

You can activate or deactivate ice cube production with the IceMaker function. Use the MaxIce function to increase the number of ice cubes in the IceMaker.

More information on the number of ice cubes:	(see 10.1 Technical specifications)		
Further information on the IceMaker water supply:	(see IceMaker water supply)		
More information on cleaning the lines of the IceMaker:	(see TubeClean)		

If the function is active, the device operates at higher power. As a result, the device's operating noise may be temporarily louder and energy consumption will increase.


#### **Activating IceMaker**

Make sure that the following requirements are fulfilled:

- ☐ The water supply is established at the fixed water connection. See installation instructions.
- ☐ IceMaker is put into operation. (see 8.11 IceMaker)



Fig. 48



► Carry out action steps according to the illustration.

#### -or-

- Activate with the SmartDevice app.
- ▷ IceMaker is activated. It can take up to 24 hours for the IceMaker to produce the first ice cubes.

#### Activating the IceMaker with MaxIce

If you have not activated the IceMaker function before, make sure that the following requirements are met:

- ☐ The water supply is established at the fixed water connection. See installation instructions.
- IceMaker is put into operation. (see 8.11 IceMaker)



Fig. 50




Fig. 51

- ► Carry out action steps according to the illustration.
- -or-
- ► Activate with the SmartDevice app.
- ➤ The IceMaker is activated with MaxIce.

#### Changing between the IceMaker and MaxIce

If you have activated the IceMaker and would like to change to MaxIce:



Fig. 52




Fig. 53

- ► Carry out action steps according to the illustration.
- > The IceMaker is activated with MaxIce.

If you have activated MaxIce and would like to change to the IceMaker:



Fig. 54




Fig. 55

- Carry out action steps according to the illustration.
- □ IceMaker is activated.

#### Deactivating the IceMaker / MaxIce



Fig. 56




Fig. 57 Example illustration of the active IceMaker function

▶ Carry out action steps according to the illustration.

#### -or-

- ▶ Deactivate with the SmartDevice app.
- ▶ IceMaker and MaxIce are deactivated.
- > If ice cubes are currently being made, the system completes the process.
- > The IceMaker goes off automatically.

# 5

#### IceMaker water supply

Use this function to set the IceMaker water supply. The IceMaker water supply regulates the amount of water supplied. The IceMaker water supply can be changed if the water supply does not match the water pressure and the ice cube size dispensed.

The IceMaker water supply is pre-set to value 5 as delivered. A value from 1 (smallest inflow volume) to 8 (largest inflow volume) can be selected.

## Setting the IceMaker water supply

Make sure that the following requirements are fulfilled:

- ☐ The IceMaker has been started. (see 4.2 Starting the IceMaker for the first time)
- ☐ IceMaker is activated. (see IceMaker / MaxIce )



Fig. 58




Fig. 59 Example illustration: Switch from value 5 to value 6.

- ► Carry out action steps according to the illustration.
- □ IceMaker water supply is set.



#### TubeClean

You can use this function to activate or deactivate Tube-Clean. If TubeClean is activated, it cleans the IceMaker lines.

#### **Activating TubeClean**

Make sure that the following requirements are fulfilled:

- ☐ IceMaker cleaning is prepared. (see 9.4.5 Cleaning the IceMaker)
- ☐ Empty container with a capacity of 1.5 l and with a maximum height of 10 cm is ready.
- ▶ Place the container in the drawer under the IceMaker.



Fig. 60





Fig. 61

- Carry out action steps according to the illustration.
- □ TubeClean is activated.
- > The cleaning process has started: Icon flashes until the cleaning process is automatically completed after 60 minutes.
- ▶ When the cleaning process is complete: The device continues to run in normal mode.

#### **Deactivating TubeClean**

TubeClean is automatically ended after 60 minutes. However, TubeClean can also be deactivated at any time during the cleaning process:



Fia. 62

- ► Carry out action steps according to the illustration.
- □ TubeClean is deactivated: Cleaning process is aborted.
- ➤ The device continues to run in normal mode.



#### CleaningMode

You can use this function to activate or deactivate Cleaning-Mode. CleaningMode enables the appliance to be cleaned conveniently.

This setting applies to the fridge section.

#### Application:

- Clean the fridge section. (see 9.4 Cleaning the appliance)

#### Device status when CleaningMode is active

The status display shows CleaningMode permanently.

The fridge section is switched off.

#### Device status when CleaningMode is active

Interior lighting is activated.

The reminders and warnings are not displayed. No signal tone sounds.

Device status

#### **Activating Cleaning Mode**



Fig. 63



Fig. 64

- ► Carry out action steps according to the illustration.
- ▷ CleaningMode is activated.
- > The status display shows CleaningMode permanently.

#### **Deactivating CleaningMode**

CleaningMode is deactivated automatically after 60 minutes. However, you can also deactivate Cleaning-Mode manually at any time:




Fig. 65

- ► Carry out action steps according to the illustration.
- CleaningMode is deactivated.
- > The appliance cools to the temperature set previously.

# -)0-

# Display brightness

Use this function to set the display brightness in stages.


You can select the following brightness levels:

- 40 %
- 60 %
- 80 %
- 100 % (pre-setting)

#### Setting the display brightness



Fig. 66



# **Controls**

Fig. 67 Example illustration: Switch from 80 % to 60 %.

- Carry out action steps according to the illustration.
- ▷ The display brightness is set.



#### Door alarm

Use this function to activate or deactivate the door alarm. The door alarm sounds if the door is open for too long. The door alarm is activated on delivery. You can set how long the door may be open before the door alarm sounds.

The following values can be set:

- 1 minute
- 2 minutes
- 3 minutes
- Off

#### Setting the door alarm



Fig. 68




Fig. 69 Example illustration: Change door alarm from 1 minute to 3 minutes.

- ► Carry out action steps according to the illustration.
- The door alarm is set.

#### Deactivating the door alarm



Fig. 71




Fig. 72

- ► Carry out action steps according to the illustration.
- > The door alarm is deactivated.



#### Input lock

You can use this function to activate or deactivate the input lock. The input lock prevents the appliance being operated accidentally, e.g. by children.

#### Application:

- Avoid unintentional modification of functions.
- Avoid unintentional switching off of the device.
- Avoid unintentional temperature setting.

#### Activating the input lock

If you activate the input lock, you can continue to navigate in the menus but you cannot select or change other functions.



Fig. 73




Fig. 74

- ► Carry out action steps according to the illustration.
- > Input lock is activated.

#### Deactivating the input lock



Fig. 75




Fig. 76

- ► Carry out action steps according to the illustration.
- ▶ Input lock is deactivated.



## Language

Use this function to set the display language.

You can select the following languages:

- Deutsch
- English
- Français
- Español
- Italiano
- Nederlands
- Čeština
- Polski
- Português
- Русский
- 温度单位

## Setting the language



Fig. 77




Fig. 78 Example illustration depending on the language and temperature

- Carry out action steps according to the illustration.
- ➤ The language is set.
- > The display returns to the status display.



#### **Device information**

Use this function to indicate the model name, index, serial number and service number of your device. You will need the device information when you contact customer service. (see 10.4 Customer Service)

This function also opens the Advanced menu. (see 3 Functionality of the Touch & Swipe display)

#### Indicating the device information



Fig. 79



- Carry out action steps according to the illustration.
- Display indicates device information.



#### Software

Use this function to indicate the software version of your device.

#### Indicating the software version



Fig. 81




Fig. 82

- Carry out action steps according to the illustration.
- Display indicates software version.



# Reminder

Reminders are given out acoustically by a beep and visually by a symbol in the display. The signal gets louder until the alert stops.



#### Replace FreshAir active carbon filter

This message appears when the air filter needs replacing.

- ► Change the air filter every six months.
- Confirm the message with OK.
- ➤ The service interval resets.
- > The air filter guarantees the air quality in the fridge.

#### Activating the setting

► Activating/deactivating.



#### Demo mode

Demo mode is a special feature for dealers who want to demonstrate appliance features. If you activate demo mode, all refrigeration functions are deactivated.


If you switch on your appliance and "Demo" appears in the status display, then demo mode is already activated.

If you activate and then deactivate demo mode, the appliance will be reset to factory defaults. (see factory settings)

#### Activating demo mode



Fig. 83



- ► Carry out action steps according to the illustration.
- Demo mode is activated.
- ▶ Appliance is switched off.
- Switch on the appliance. (see 4.1 Switching on appliance (first use))

> "DEMO" appears in the status display.

#### **Deactivating demo mode**



Fig. 85




Fig. 86

- ► Carry out action steps according to the illustration.
- Demo mode is deactivated.
- ▷ Appliance is switched off.
- ➤ Switch on the appliance. (see 4.1 Switching on appliance (first use))
- ▶ Appliance is reset to factory settings.



## Resetting to factory settings

Use this function to reset all settings to factory defaults. All settings you have made so far are reset to their original settings.

#### Performing a reset



Fig. 87




Fig. 88

- ► Carry out action steps according to the illustration.
- Device is reset.
- Device is switched off.
- ► Restart the device. (see 4.1 Switching on appliance (first use))

# 7.3 Fault messages

Fault messages appear in the display. There are two categories of fault message:

Category	Meaning
Message	Reminder of general procedures. You can carry out these procedures to eliminate the message.
Warning	Appears when there are malfunctions. A signal sounds in addition to the display. The signal becomes louder until you acknowledge by tapping the display. You can eliminate simple defects yourself. For more serious defects, you must contact customer service.

# 7.3.1 Warnings



#### Close the door

This message appears if the door is open for too long.

You can set how long it takes for this message to appear . > Stop alarm: Confirm the message.

-or-

Close the door.



#### Power cut

This message appears if the freezer temperature increased due to a power cut. After the power is restored, the appliance continues to work at the set temperature.

- ► Stop alarm: Confirm the message.
- ▷ Temperature alert appears (see Temperature alarm).



#### Temperature alarm

This message appears if the freezer temperature does not match the set temperature.

Variations in temperature could be because:

- Hot, fresh food was inserted.
- Too much warm room air flowed in when rearranging and removing food.
- The power was cut off for a while.
- The appliance is faulty.

When the fault is eliminated the appliance continues to work at the set temperature.

- ► Confirm the display.
- ➤ The highest temperature is shown.
- ► Confirm display again.
- ightharpoonup The status display is displayed.
- ▷ The current temperature is shown.



#### Error

This message appears if there is a fault with the appliance. An appliance component indicates a fault.

- ▶ Open the door.
- Note down the fault code.
- ► Confirm the message.
- $\triangleright$  The signal tone stops.
- ▷ The status display appears.
- Close the door.
- Contact customer service. (see 10.4 Customer Service)

#### 7.3.2 Message



#### Insert IceMaker drawer

This message appears if the IceMaker drawer is open.

- ▶ Push in the IceMaker drawer.
- ightharpoonup The message disappears.
- ➤ The IceMaker produces ice cubes.

# 8 Features

#### 8.1 Door rack

#### 8.1.1 Move/remove the door rack




Fig. 89

- ► Slide the rack upwards.
- ▶ Pull forwards.
- ► Re-insert it in reverse order.




Fig. 90

You can use just one or both VarioBoxes. To store oversized bottles, just suspend one box over the bottle rack.

#### Move the VarioBox shelf:




Fig. 91

- ▶ Pull it up and out.
- ▶ Put it back in at any position.

#### Moving the VarioBoxes:




Fig. 92

If the door rack is removed:

► Remove containers.




Fig. 93

▶ Place the shelf on the table.




Fig. 94

- ▶ Pull off the middle holder Fig. 94 (1).
- ▶ Insert the middle holder in the second position Fig. 94 (2).




Fig. 9

► Replace containers.

# 8.1.2 Disassembling the door rack

The door rack can be taken apart for cleaning.




Fig. 96




Fig. 97

▶ Disassemble the door rack.

# 8.2 Shelves

# 8.2.1 Adjusting/removing the shelves

The shelves are prevented from being pulled out accidentally by pull out stops.




Fig. 98

- ► Lift the shelf and pull forward.
- □ Line up the side runner.
- ► Adjust the height of the shelf: Lift or lower it to the desired height and slide it in.

-or-




Fig. 99

- ▶ Remove the shelf completely: Pull it out to the front.
- ► Easier removal: Set the shelf at an angle.
- ▶ Insert the shelf again: Slide it in all the way.
- The pull-out stoppers point downwards.
- ${igle}$  The pull-out stoppers are behind the front support.

# 8.2.2 Dismantling the shelves\*

The shelves can be dismantled for cleaning.




Fig. 100

▶ Dismantling the shelf.

# 8.3 Dividing shelf

# 8.3.1 Using the dividing shelf

The shelves are prevented from being pulled out accidentally by pull out stops.




Fig. 101

▶ Push the dividing shelf underneath as shown.




Fig. 102

#### Adjusting the height:

- ▶ Pull the glass panels out Fig. 102 (1) from the front, one at a time.
- ▶ Release the support rails and click in at the height you want.
- ▶ Slide in the glass panels one at a time.
- > Flat pull-out stoppers at the front, right behind the support rails.

#### Using both shelves:

- Hold the glass panel with one hand and pull it to the front
- $\triangleright$  The glass panel Fig. 102 (1) and trim strip are at the front.
- The stops Fig. 102 (3) point down.

# 8.4 Space for baking tray

There is space for a baking tray Fig. 1 (6) above the drawers.




Fig. 103

Ensure that the following conditions are met:

- ☐ Max. baking tray dimensions are adhered to (see 10.1 Technical specifications).
- ☐ Baking tray is cooled to room temperature.
- ☐ The lowest door rack is set at least one position higher. With the door open to 90°:
- ► Slide the baking tray onto the lower side runners.

-or-

If baking tray is uneven:

Use the supplied support rails.




Fig. 104

- ➤ Snap support rails into the lowest runners. With the door open to 90°:
- ► Slide the baking tray in on the support rails.

# 8.5 Adjustable bottle shelf

#### 8.5.1 Using the bottle shelf

In the bottom of the fridge section you can either use the variable bottle shelf or the glass panel.




Fig. 105

- ▶ Remove the glass panel and store in a safe place.
- ▶ Lay bottles with their base towards the rear wall.

#### Note

If the bottles are protruding over the front of the bottle shelf:

▶ Move the lower door rack up a place.

#### 8.5.2 Removing the bottle shelf

You can remove the bottle shelf for cleaning.

► Remove the glass panel above the bottle shelf.




Fig. 106

▶ Lift the bottle shelf at the front and pull out.

#### Note

Liebherr recommends the following:

Do not place any goods on the drawer cover below.

## 8.5.3 Inserting the bottle shelf




Fig. 107

- ▶ Slide in the bottle shelf until it engages and push down.
- > The lugs at the back of the bottle shelf are connected automatically.
- LED comes on.

#### 8.6 Drawers

You can remove the drawers for cleaning.

You can remove the drawers to use VarioSpace.

The way to remove/insert the drawers varies depending on the pull-out system. Your appliance can contain various pull-out systems.

#### Note

The energy consumption increases and the cooling power goes down if ventilation is not sufficient.

- Leave the bottom drawer in the appliance!
- ▶ Always leave the fan air vents clear on the back wall!

# 8.6.1 Drawer on appliance base or glass shelf

The drawer runs directly on the appliance base or on a glass shelf. There are no rails.

When you remove the drawers, you can use the glass shelves below them as storage shelves.

#### Removing drawer




Fig. 108

▶ Remove drawer as shown in the illustration.

#### Inserting drawer




Fig. 109

▶ Insert drawer as shown in the illustration.

#### 8.6.2 Drawer on telescopic rails

The drawer runs on extendible rails (telescopic rails). There are fully extendible telescopic rails and telescopic rails with partial pull-out. Drawers which are fully extendible can be pulled out fully from the appliance. Drawers with partial pull-out cannot be removed fully from the appliance. The system in your appliance depends on the type of appliance.

#### Fully extendible\*

If you have fully extendible rails, there is a clamp located at the back on the left and right of the rail.

#### Removing drawer




Fig. 110

- ▶ Pull out drawer as far as it will go.
- ▶ Lift left clamp and simultaneously pull drawer forwards on the left. Fig. 110 (1)
- ► Lift right clamp and simultaneously pull drawer forwards on the right. Fig. 110 (2)
- ► Remove drawer to the front. Fig. 110 (3)
- ► Slide rails in.

#### Inserting drawer




Fig. 111

- ► Slide rails in.
- ▶ Place drawer on rails.
- ▶ Slide in drawer to the back.
- Drawer latches in audibly at the back.

#### Partial pull-out fridge compartment\*

#### Removing drawer





Fig. 112

- ▶ Pull out drawer half-way. Fig. 112 (1)
- ▶ Push the drawer down at the front. Fig. 112 (2)
- ▶ Push the left rail in by about 2 cm. Fig. 112 (3)
- ▶ Push the right rail in by about 2 cm. Fig. 112 (4)
- ▶ Remove drawer to the front. Fig. 112 (5)



#### Fig. 113

If the rails are not yet fully inserted after removing the drawer:

► Push rails in completely.

#### Inserting drawer




Fig. 114

- Slide rails in.
- ▶ Place drawer on rails.
- ► Slide in drawer to the back.

#### Partial pull-out freezer compartment

#### Note

If the magnet on the top drawer in the freezer compartment is damaged or removed, the door sensors will malfunction.

▶ Do not damage or remove the magnet.

#### Removing drawer




Fig. 115

If the drawer is in the top freezer:

- ▶ Pull out drawer as far as it will go.
- ▶ Lift up drawer at the front. Fig. 115 (1)
- ► Remove drawer to the front. Fig. 115 (2)
- ➤ Slide rails in.

-or-




Fig. 116

If the drawer is in the middle part of the freezer compartment:

- ► Pull out drawer half-way.
- ▶ Lift drawer from below. Fig. 116 (1)
- ► Remove drawer to the front. Fig. 116 (2)
- ► Slide rails in.

#### Inserting drawer




Fig. 117

- Slide rails in.
- ▶ Guide drawer around the stoppers Fig. 117 (1).
- Place drawer on rails.
- Slide in drawer to the back.

# 8.7 Fruit & Vegetable safe cover

You can remove the compartment cover for cleaning.

#### 8.7.1 Removing the compartment cover

Ensure that the following conditions are met:

☐ Bottle shelf is removed (see 8.5 Adjustable bottle shelf) .




Fig. 118

When the drawers are removed:

- ▶ Pull the lid up at the front to the opening in the retaining parts Fig. 118 (1).
- ▶ Lift from the back and pull it up and out Fig. 118 (2).

#### 8.7.2 Inserting the compartment cover




Fig. 119

If the text THIS SIDE UP points upwards:

- ▶ Insert the lip of the cover over the opening of the rear bracket *Fig. 119 (1)* and click into place *Fig. 119 (2)*.
- ► Position the cover where you want it (see 8.8 Adjusting the moisture levels).

# 8.8 Adjusting the moisture levels

You can adjust the moisture in the drawer yourself by adjusting the compartment cover.

The compartment lid is attached to the drawer and can be hidden by a shelf or additional drawers.




Fig. 120

#### Low air humidity

- ▶ Open the drawer.
- ► Slide the compartment cover forwards.

- With the drawer closed: Gap between the cover and the compartment.
- ► Switch off HydroBreeze.
- > The air moisture in the Safe decreases.

#### High air moisture

- Open the drawer.
- ► Slide the cover back.
- ▶ With the drawer closed: The cover seals the compartment.
- ► Activate the HydroBreeze.
- > The air moisture in the Safe increases.
  - If there is too much moisture in the compartment:
- ► Choose the setting "low air moisture".

#### -or-

► Remove any excess moisture with a cloth.

#### Note

You can apply the "low air moisture" setting to the Fruit & Vegetable-Safe and the Meat & Dairy-Safe.

► Set the "low air moisture" option.

# 8.9 HydroBreeze

HydroBreeze emits a mist over the refrigerated goods to provide moisture every time the door is opened.

The HydroBreeze and its water tank are located in the adjustable bottle shelf.

Ensure that the following conditions are met:

- The water tank is clean (see 9.4.3 Clean the components).
- The water tank is properly engaged.
- Moisture is set to "high moisture" (see 8.8 Adjusting the moisture levels).
- HydroBreeze is on (see HydroBreeze).

#### 8.9.1 Fill the water tank



#### WARNING

Unclean water!

Contaminants.

- ► Only fill with drinking water.
- ► The HydroBreeze is off: empty water tank.
- ▶ The HydroBreeze is no longer in use: empty water tank.

#### **NOTICE**

Sugar-content liquids!

Damage to HydroBreeze.

► Only fill with drinking water.

#### Note

Only use filtered, decarbonised water for the best quality drinking water and to make the HydroBreeze, work smoothly.

This water quality can be achieved using a table water filter of the kind available in trade retail outlets.

► Only ever fill the water tank with filtered, decarbonised drinking water.

The water tank is built into the adjustable bottle shelf (see 1.2 Overview of the appliance and equipment).




Fig. 121

- ▶ Press on the back-left corner of the front glass plate.
- > The glass panel folds up at the front.
- ▶ Lift the glass panel and fold towards the rear until it clicks into place Fig. 121 (1).
- ▶ Slide the slider *Fig. 121 (2)* to the left.
- > The water tank jumps out of its recess.
- ► Remove the water tank Fig. 121 (3).
- Cleaning the water tank (see 9.4.3 Clean the components).
- Square opening:
- Fill with drinking water up to the marker.
- ▶ Insert the water tank into the recess, bottom first.
- ► Slowly lower the front part and push the tank in.
- > The water tank is clicked into place.

#### 8.9.2 Dismantling the water tank

You can take the water tank apart for cleaning.




Fig. 122

▶ Dismantling the water tank.

#### 8.10 Glass shelves

You can remove the glass shelves under the drawers for cleaning.

You can remove the glass shelves under the drawers to use VarioSpace.

# 8.10.1 Removing / inserting the glass shelf

Make sure that the following requirements are fulfilled:

☐ Glass shelf under the drawer: The drawer has been removed. (see 8.6 Drawers)

#### Removing glass shelf




Fig. 123 Example illustration of glass shelf

- ▶ Lift glass shelf at the front. Fig. 123 (1)
- ► Take out glass shelf to the front. Fig. 123 (2)

#### Inserting glass shelf




Fig. 124 Example illustration of glass shelf

- Position glass shelf at an angle behind the stoppers. (see Fig. 124)
- Lower glass shelf.
- ► Slide in glass shelf to the back.

#### 8.11 IceMaker

The IceMaker will produce ice cubes for household use only.

Ensure that the following conditions are met:

- IceMaker is cleaned (see 9 Maintenance) .
- IceMaker drawer is cleaned.
- IceMaker drawer is fully inserted.

#### 8.11.1 Producing ice cubes

The volume depends on the freezing temperature. The colder the temperature, the more ice cubes the system can produce in a certain time period.

After the IceMaker is turned on for the first time, it can take up to 24 hours for the first ice cubes to be made.

- Activate the IceMaker function .
- To make a high number of ice cubes: Activate the MaxIce function.
- ► To make a high number of ice cubes: Move the divider in the IceMaker drawer or remove it completely.
- ▶ Distribute the ice cubes evenly in the drawer to increase the capacity.
- Closing the drawer: IceMaker starts making ice cubes again automatically.

#### Note

When a certain level is reached in the IceMaker drawer, it stops producing ice cubes. The IceMaker does not fill the drawer all the way to the top.

# 8.11.2 Using the drawer with the IceMaker deactivated

If you deactivate the IceMaker, then you can use the entire IceMaker drawer as a freezer drawer.

Deactivate IceMaker. (see Deactivating the IceMaker / MaxIce)




Fig. 125

- Place food in drawer.
  If you put food in the left side of the drawer:
- ▶ Watch out for the IceMaker Fig. 125 (1).

# 8.12 VarioSpace




Fig. 126

You can remove drawers and glass panels from your appliance. This provides more room for large food items such as poultry, joints of meat, large game, and tall baked products. You can then freeze these items whole for later preparation.

► Note the weight limits on the drawers and glass panels (see 10.1 Technical specifications).

## 8.13 Butter dish

# 8.13.1 Opening/closing the butter dish




Fig. 127

#### 8.13.2 Dismantling the butter dish

You can take the butter dish apart for cleaning.





Fig. 128

▶ Disassembling the butter dish.

# 8.14 Egg rack

You can pull out and turn the egg rack. You can use both sides of the egg rack so you can label specifics like the purchase date.

## 8.14.1 Using the egg rack



Fia 129

- Top layer: for storing hen eggs.
- ► Bottom layer: for storing quail eggs.

#### 8.15 Bottle holder

#### 8.15.1 Using the bottle holder





Fig. 130

- ▶ Push the bottle holder onto the bottles.
- > The bottles are prevented from falling over.

#### 8.15.2 Removing the bottle holder



# **Features**

Fig. 131

- ► Move the bottle holder all the way to the right.
- ▶ Push the bottle holder to the back to remove.

# 8.16 FlexSystem

#### 8.16.1 Using the FlexSystem

The FlexSystem helps you store and organise your food in a clear and flexible way. It lets you clearly divide your food into fruit, vegetables or by use-by dates, for example.




Fig. 132

► Move the inner shell.

# 8.16.2 Removing the FlexSystem




Fig. 133

- ► Lift the FlexSystem from the back.
- ▶ Pull up and out.

#### 8.16.3 Inserting the FlexSystem




Fig. 134

- ► Insert the FlexSystem front-first.
- ► Lower the rear part.

#### 8.16.4 Disassembling the FlexSystem

You can take the FlexSystem apart for cleaning.




Fig. 135

▶ Disassembling the FlexSystem

# 8.17 Freezer pack

Freezer packs prevent the temperature rising too quickly should there be a power cut.

The freezer packs are in the drawer.

You can store the freezer packs in the freezer tray.

# 8.17.1 Using the freezer pack




Fig. 136

- When the freezer packs are fully frozen:
- ▶ Place on the frozen goods in the top, front part of the freezer.

# 8.18 Flexible ice compartment divider

The IceMaker's ice cube drawer has a flexible ice compartment divider. This allows you to store larger quantities of ice cubes or additional food items as needed. You can move or remove the ice compartment divider.

# 8.18.1 Moving in the flexible ice compartment divider




Fig. 137 Example illustration of the ice compartment divider

▶ Move the ice compartment divider to the desired position.

# 8.18.2 Removing the flexible ice compartment divider

Make sure that the following requirements are fulfilled:

☐ Ice cube drawer is removed. (see 8.6 Drawers)




Fig. 138

- ▶ Lift the rear part of the ice compartment divider. Fig. 138 (1)
- ▶ Remove the ice compartment divider upwards. Fig. 138 (2)

# 8.18.3 Putting in the flexible ice compartment divider

Make sure that the following requirements are fulfilled:

☐ Ice cube drawer is removed. (see 8.6 Drawers)




Fig. 139

- ► Insert the front part of the ice compartment divider. Fig. 139 (1)
- ▶ Lower the rear part of the ice compartment divider to the drawer bottom. Fig. 139 (2)

# 9 Maintenance

#### 9.1 FreshAir carbon filter

The FreshAir carbon filter is in the compartment above the fan.

It guarantees the best air quality.

- Replace the carbon filter every 6 months. When the reminder is set, a message on the display prompts you to change it.
- ☐ The carbon filter can be disposed of with the regular household waste.

#### Note

FreshAir activated charcoal filters can be purchased from the Liebherr-Hausgeräte store at home.liebherr.com/shop/de/deu/zubehor.html.

#### 9.1.1 Removing the FreshAir carbon filter




Fig. 140

- ▶ Pull out the compartment Fig. 140 (1).
- ▶ Remove the carbon filter Fig. 140 (2).

# 9.1.2 Inserting the FreshAir carbon filter




Fig. 141

- ▶ Insert the carbon filter as shown in the diagram Fig. 141 (1).
- ▶ The carbon filter clicks into place. If the carbon filter is pointing downwards:
- ▶ Push the compartment in Fig. 141 (2).
- The carbon filter is now ready for use.

# 9.2 Disassembling / assembling pullout systems

#### 9.2.1 Notes on disassembly

You can disassemble some of the pull-out systems for cleaning. Your appliance can contain a variety of pull-out systems.

The following pull-out systems can be disassembled or cannot be disassembled:

Pull-out system	can be disassembled / cannot be disassembled		
Drawer on appliance base or glass shelf	cannot be disassembled		
Fully extendible*	cannot be disassembled*		
Partial pull-out fridge compartment*	cannot be disassembled*		
Partial pull-out freezer compartment	can be disassembled (see Partial pull-out freezer compartment)		

#### 9.2.2 Drawer on telescopic rails

#### Partial pull-out freezer compartment

#### Disassembling pull-out system

Make sure the following prerequisites are met:

- □ Drawer has been removed.
- ☐ Glass shelf has been removed. (see 8.10 Glass shelves)




Fig. 142 Glass shelf with rails

- ▶ Push up front click-in hooks. Fig. 142 (1)
- ▶ Move the pull-out rails to the side Fig. 142 (2) and to the rear Fig. 142 (3).

#### Installing pull-out system




Fig. 143 Glass shelf with rails

- ► Hook in rail at the back. Fig. 143 (1)
- ► Hook in rail at the front. Fig. 143 (2)

# 9.3 Defrosting the appliance

#### 9.3.1 Defrosting the fridge compartment

Defrosting is performed automatically. The water from the thawing process drains through the outlet and evaporates.

► Clean the drain opening regularly (see 9.4 Cleaning the appliance).

# 9.3.2 Defrosting the freezer compartment with NoFrost

Defrosting is performed automatically with the NoFrost system. The moisture is deposited on the evaporator, is periodically defrosted and evaporates.

The appliance does not need to be defrosted.

# 9.4 Cleaning the appliance

#### 9.4.1 Ready



#### WARNING

Danger of electric shock!

Remove the refrigerator connector or interrupt the power supply.



#### **WARNING**

Risk of fire

Do not damage the refrigeration circuit.

- ► Empty the appliance.
- ► Remove mains connector.

-or-

► Activate CleaningMode. (see CleaningMode)

#### 9.4.2 Cleaning the interior

#### **NOTICE**

Improper cleaning!

Damage to the appliance.

- ▶ Only use soft cleaning cloths and ph-neutral all-purpose cleaners.
- ▶ Do not uses abrasive sponges or steel wool which may cause scratches.
- Do not use any sharp or abrasive cleaning agents, nor any that contain sand, chloride or acid.
- ▶ Plastic surfaces: clean by hand with a soft clean cloth, lukewarm water and a little detergent.
- ► Metal surfaces: clean by hand with a soft clean cloth, lukewarm water and a little detergent.
- ► Drain hole: remove deposits using a thin item (for example a cotton bud).

#### 9.4.3 Clean the components

#### NOTICE

Improper cleaning!

Damage to the appliance.

- ► Only use soft cleaning cloths and ph-neutral all-purpose cleaners
- Do not uses abrasive sponges or steel wool which may cause scratches.
- ▶ Do not use any sharp or abrasive cleaning agents, nor any that contain sand, chloride or acid.

# Clean with a soft, clean cloth, lukewarm water and some detergent:

- Fruit & Vegetable safe cover
- Drawer

Please note: Do not remove the magnet on the drawer. The magnet ensures the functionality of the IceMaker.

- Divider in the IceMaker drawer
- Adjustable bottle shelf
- FlexSystem
- Freezer tray

#### Clean with a damp cloth:

- Retractable rails

Please note: The grease in the tracks is used for lubrication and must not be removed!

#### Wash in the dishwasher up to 60 °C:

- Door rack
- VarioBox
- Bottle rack
- Shelf
- Dividing shelf
- Holder of the dividing shelf
- HydroBreeze water tank and water tank lid
- Egg rack
- Butter dish
- Ice cube scoop
- To disassemble components: see the relevant section.
- ► Clean the components.

#### 9.4.4 Cleaning the HydroBreeze

Cleaning is required in the following cases:

- Initial operation
- ☐ HydroBreeze is off for more than 48 hours.
- ☐ Refill the water tank.

Ensure that the following conditions are met:

- ☐ HydroBreeze is off (see HydroBreeze).
- Water tank has been removed and cleaned in the dishwasher.
- ▶ Wipe out the recess with a damp cloth.
- ► Insert the water tank.
- ► Activate the HydroBreeze.

#### 9.4.5 Cleaning the IceMaker

There are various options for cleaning the IceMaker.

Cleaning is required in the following cases:

■ Initial operation

☐ With mains connection:

If out of use for more than 5 days.

Ensure that the following conditions are met:

- ☐ IceMaker drawer is emptied.
- ☐ IceMaker drawer is in place.
- ☐ The IceMaker is activated.

#### First use or after a long period of non-use

Clean the IceMaker with the TubeClean function.

- ▶ Put an empty 1.5 l vessel (max. height 10 cm) in the drawer under the IceMaker.
- Activate the TubeClean function.
- The rinse process is prepared (max. 60 min.): Symbol flashes.
- > Water pipes are rinsed: Symbol flashes.
- Rinsing process is complete: Function turns off automatically.
- ▶ Remove the IceMaker drawer and remove the container.
- Clean the IceMaker drawer with warm water and a little detergent.
- Push the IceMaker drawer in.
- > The system starts making ice cubes automatically.
- ▶ Dispose of any ice cubes that were made 24 hours after the first ice cubes.

#### If cleaning is required

Clean the IceMaker by hand.

- Remove the IceMaker drawer and clean with warm water and a little detergent.
- ► Push the IceMaker drawer in.
- > The system starts making ice cubes automatically.

#### 9.4.6 After cleaning

- ▶ Wipe the appliance and the components dry.
- ► Connect and switch on the appliance.
- Activate SuperFrost (see 7.2 Appliance functions). The temperature is cold enough:
- ▶ Place the food inside.
- ► Repeat cleaning regularly.

# 10 Customer help

# 10.1 Technical specifications

Temperature range	
Cooling	3 °C to 9 °C
BioFresh	0 °C to 3 °C
Freeze	-26 °C to -15 °C

Maximum freezing quantity/24 h						
Freezer ment	compart-	See "Freezing the type plate	capacity	/24	h"	on

Maximum component capacity			
Features	Appliance width 550 mm (see installation instructions, appliance dimensions)	Appliance width 600 mm (see installation instructions, appliance dimensions)	Appliance width 700 mm (see instal- lation instruc- tions, appli- ance dimen- sions)
Drawer on glass shelf (see 8.6.1 Drawer on appliance base or glass shelf)	12 kg	15 kg	<del></del>
Partial pull-out freezer compart- ment (see 8.6.2 Drawer on telescopic rails)	12 kg	15 kg	

Maximum size baking tray	
Width 466 mm	
Depth	386 mm
Height	50 mm

Ice cube production with IceMaker		
Ice cube production/24 h At a temperature of -18 °C: 1.2 kg of ice cubes		
	With the MaxIce function on: 1.5 kg of ice cubes	

Time required to reach various temperatures with Vario- Temp			
Initial temperature	Target tempera- ture	Time required to reach target temperature	
-18 °C	0 °C	>8 h	
-18 °C	8 °C	>12 h	
8 °C	14 °C	>6 h	
14 °C	-18 °C	>4 h	

# 10.2 Operating noises

The appliance makes different noises when it is on.

- At higher temperatures the appliance uses less energy but works for longer. It is quieter.
- At lower temperatures the food is cooled faster. It is louder.

#### Examples:

- Functions on (see 7.2 Appliance functions)
- Fan running
- Food recently added
- High ambient temperature
- Door open for a while

# **Customer help**

Noise	Possible cause	Type of noise
Bubbling and splashing	Coolant flowing into the cooling circuit.	Normal operating noise
Hissing	Coolant sprays into the cooling circuit.	Normal operating noise
Humming	The appliance is cooling. The volume depends on the cooling output.	Normal operating noise
Suction noises	Soft-closing door is being opened and closed.	Normal operating noise
Humming and rustling	The fan is running.	Normal operating noise
Clicking	Components are switched on and off.	Normal switching noise
Rattling or humming	Valves or flaps are working.	Normal switching noise

Noise	Possible cause	Type of noise	Lifting
Vibration	Improper installation	Defective noise	Check the installation.
			Level the appliance.

Noise	Possible cause	Type of noise	Lifting
Rattling	Components, items inside the appliance	Defective noise	Secure components. Leave enough space between the items.

## 10.3 Technical fault

Your appliance is designed and built to ensure it works reliably and has a long service life. In the unlikely event that a fault occurs during operation, please check whether it is due to an operating error. If so, you will be charged for the callout and repair costs even if it falls within the warranty period.

You can fix the following faults yourself.

## 10.3.1 Appliance function

Defect	Cause	Remedy
The appliance is	→ The appliance is not switched on.	► Switch the appliance on.
not working.	→ The power plug is not properly plugged into the socket.	► Check the power plug.
	→ There is something wrong with the power outlet fuse.	► Check the fuse.
	→ Power cut	<ul> <li>Keep the appliance closed.</li> <li>Protecting food: Lay freezer packs on top of the food or use another freezer if the power is off for a prolonged period.</li> <li>Do not re-freeze defrosted food,</li> </ul>
	→ The appliance plug does not fit the appliance properly.	► Check the appliance plug.
Temperature is not cold enough.	→ The appliance door is not closed properly.	Close the appliance door.
_	→ Not enough ventilation.	► Keep ventilation grille clear, and clean it.
	→ The ambient temperature is too high.	▶ Problem solution: (see 1.4 Appliance range of use)
	→ The appliance was opened too many times or for too long.	► Wait to see if the required temperature corrects itself. If not, contact Customer Service. (see 10.4 Customer Service)
	→ Too much fresh food was placed inside without SuperFrost.	► Solution: (see SuperFrost)
	→ The temperature is set incorrectly.	► Turn down the temperature and check after 24 hours.

Defect	Cause	Remedy
	→ The appliance is too close to a heat source (oven, radiator, etc).	► Move the appliance or the heat source.
	→ The appliance was not correctly installed in the recess.	► Check if the appliance was installed correctly and that the door closes properly.
The door seal is defective or needs to be replaced for another reason.	→ The door seal can be replaced. It can be replaced without the need for special tools.	► Contact Customer Service. (see 10.4 Customer Service)
The appliance builds up too much ice or condensation.	→ The door seal may have slipped out of its groove.	► Check that the door seal is well fitted in the groove.

#### 10.3.2 Features

Defect	Cause	Remedy
You cannot activate the IceMaker.	→ The appliance and therefore the IceMaker are not connected.	► Connect the appliance (see the Installation Guide).
The IceMaker is	→ The IceMaker is not on.	Activate the IceMaker.
not producing ice cubes.	→ The drawer of the IceMakers is not connected properly.	► Push the drawer in correctly.
	→ The water connection is not open.	▶ Open the water connection.
HydroBreeze is not	→ The HydroBreeze is not on.	► Activate the HydroBreeze.
keeping refriger- ated goods moist.	→ There is not enough water in the water tank.	► Fill the water tank.
	→ There is dirt in front of the concentrator.	► Clean the HydroBreeze.
	→ The water tank is not clicked into place properly.	Click the water tank into place.
	→ The cover of the Fruit & Vegetable- Safe is in "low air moisture" mode.	Set the Fruit & Vegetable-Safe to the "high air moisture" mode.
The internal light	→ The appliance is not switched on.	Switch the appliance on.
does not come on.	→ The door was open for longer than 15 minutes.	Interior lighting turns off automatically after approx. 15 min. with the door open.
	→ The LED interior light is faulty or the lid is damaged.	► Contact Customer Service. (see 10.4 Customer Service)

## 10.4 Customer Service

First check whether you can rectify the fault yourself (see 10 Customer help) . If you cannot rectify the problem, contact Customer Service.

You can find the address at home.liebherr.com/service.



#### WARNING

Unprofessional repair! Injuries.

- ► Have any repairs and action not expressly specified on the appliance and mains cable carried out by service personnel only. (see 9 Maintenance)
- ► A damaged mains cable may only be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person.
- ▶ In the case of appliances with an IEC connector, the change may be made by the customer.

# **Shutting down**

#### 10.4.1 Contacting Customer Service

Make sure that the following appliance information is available:

- Appliance name (model and index)
- ☐ Service no. (Service)
- ☐ Serial no. (S no.)
- ► Call up the appliance information via the display. (see Device information)

-or-

- ► Refer to the type plate for appliance information. (see 10.5 Model plate)
- ▶ Note down the appliance information.
- ► Notify customer service: Report errors and the appliance information.
- This will help us to provide you with a faster, more accurate service.
- ► Follow further instructions from Customer Service.

# 10.5 Model plate

The model plate is behind the drawers on the inside of the appliance.




Fig. 144

- (1) Appliance description
- (3) Serial no.
- (2) Service no.
- Note the data on the model plate.

# 11 Shutting down

- ► Empty the appliance.
- Deactivate IceMaker. (see Deactivating the IceMaker / MaxIce)
- Switch off appliance. (see Turn off appliance)
- ► Remove mains connector.
- ► Remove appliance connector if required: Remove and move from left to right at the same time.
- ► Clean appliance. (see 9.4 Cleaning the appliance)
- ▶ Leave the door open, so that no unpleasant odours arise.

# 12 Disposal

# 12.1 Preparing appliance for disposal



Liebherr uses batteries in some of its appliances. In the EU, for environmental reasons, legislation obliges the end user to remove these batteries before disposing of old appliances. If your appliance contains batteries, a corresponding notice is attached.

Lamps

If you can remove the lamps yourself without destroying them, also remove these before disposal.

- ► Take the appliance out of operation.
- Appliances with batteries: remove the batteries. For description, see Maintenance chapter.
- ▶ If possible: remove lamps without destroying them.

# 12.2 Disposing of the appliance in an environmentally friendly manner



The appliance still contains valuable materials and must be disposed of separately from unsorted municipal waste.





from the old appliance. To do this, you can return the batteries free of charge to retailers as well as recycling centres and collection centres for recyclable materials.

Dispose of batteries separately

Lamps

Dispose of removed lamps via the respective collection systems.



# WARNING

Leaking coolant and oil!

Fire. The coolant contained in the appliance is eco-friendly, but also flammable. The oil contained in the appliance is flammable. Escaping coolant and oil can ignite if the concentration is high enough and in contact with an external heat source.

- ► Do not damage the pipelines of the coolant circuit and the compressor.
- Transport the appliance without damaging it.
- ▶ Dispose of batteries, lamps and the appliance according to the above specifications.



home.liebherr.com/fridge-manuals

integrated fridge/freezer with BioFresh