Ways to install a freestanding wine cellar

FREESTANDING

LIEBHERR Comp. (A) P. (

BUILT IN CAVITY (WITH CLEARANCE)



If building into cavity, please note the below requirements:

Minimum air space above cabinet (mm): 50mm Minimum air space behind cabinet (mm): 50mm Minimum air space on sides of cabinet (mm): 15mm

BUILT IN CAVITY WITH VENTILATION (AIR SPACE OUT OF TOP OF BENCH)





If building into cavity with ventilation cut out, please note the below requirements:

Ventilation opening/grille: Minimum 300cm² at top rear of cabinet. Minimum air space above cabinet (mm): 15mm Minimum air space behind cabinet (mm): 50mm Minimum air space on sides of cabinet (mm): 15mm

