


Icemaker water connection information



*Position of water connection if a 1.5m hose is used.
*This hose is supplied with the appliance as standard.

1. Connection to cold water only.
2. $\frac{3}{4}$ inch / 20mm male connection required.
3. Water pressure must be between 150kPa and 600kPa.
4. Shut off valve must be installed in an accessible location i.e adjacent cupboard.
5. Hose length of 1500mm, recommended shut off valve location: Immediately adjacent to the freezer with the shaded area.
6. Pre flush tap system before installing the water connection.
7. To be read in conjunction with the installation instructions supplied with the appliance

PLEASE NOTE:

- For '**Freestanding Side by Sides**' the plumbing must be installed to the left of the appliance only.
- For '**Integrated Side by Sides**' the plumbing must be installed adjacent to the side of the appliance which contains the IceMaker.

LIEBHERR