
# LIEBHERR

# **Installation Instructions**

For Fully Integrated Freezer



MF 1851 / MF 2451 / MF 3051 / MF 3651 7085 998-00

## Please Read and Follow these Instructions

These instructions contain Danger, Warning and Caution notes.

This information is important for safe and efficient installation and operation.

Always read and comply with all Danger, Warning and Caution notes!

## **⚠** DANGER!

Danger indicates a hazard which will cause serious injury or death if precautions are not followed.

## | ∕!\ WARNING! |

Warning indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

## **∴** CAUTION!

Caution indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

#### **IMPORTANT**

This indicates information that is especially relevant to a problem-free installation and operation.

#### Note to the Installer

It is very important to follow the instructions in the manual to ensure proper installation and operation of the unit.

Before installing the unit, be sure to thoroughly read and understand all of the information in this manual.



Electrocution hazard.

Do not connect to the electrical outlet before the installation is completed.

Content	Page
Please Read and Follow these Instructions	2
Note to the Installer	2
R600a Refrigerant	2
Disposal of Old Appliance	3
Disposal of Packaging Material	3
Electrical Safety	3
Blocking for Safety	3
Appliance Dimensions	4
Door Swing Clearance (top view)	5
Cabinet Opening Dimensions	6
Panel Dimensions	8
Unpacking	10
Standard Accessories	12
Anti-tipping device	13
Safety Instructions and Warnings for Water Connection	n15
Water Connection Requirements	15
Appliance Installation	15
SmartDeviceBox (Not Supplied in All Countries)	24
Please note in case of removing appliance from the	е
recess	24
Important Note for Changing over Door Hinges or	
Limiting the Hinges to a 90° Opening Angle	24

## **R600a Refrigerant**



The refrigerant R600a contained within the appliance is environmentally friendly, but flammable. Leaking refrigerant can ignite.

To prevent possible ignition, follow the warnings below:

- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not damage the refrigerant circuit.
- Component parts and power cords shall be replaced with like components performed by factory authorized service personnel only.



### **Disposal of Old Appliance**



#### Risk of child entrapment.

Child entrapment and suffocation are not problems of the past.

Junked or abandoned refrigerators are still dangerous – even if they will sit for "just a few days."

If you are getting rid of your old refrigerator, please follow these instructions to help prevent accidents.

#### Before you discard old appliances:

- · Take off the doors.
- Leave the shelves in place so that children may not easily climb inside.
- Cut off the power cable from the discarded refrigerator. Discard separately from the refrigerator.
- Be sure to follow your local requirements for disposal of appliances.

Contact the trash collection agency in your area for additional information.

## **Disposal of Packaging Material**



Keep packaging materials away from children. Polythene sheets and bags can cause suffocation!

If possible, please recycle packaging material at a recycling facility.

## **Electrical Safety**

Connect this appliance to a 15 amp or 20 amp, 110-120 VAC circuit which is grounded and protected by a circuit breaker or fuse.

We recommend using a dedicated circuit for this appliance to prevent circuit overload and the chance of interruption to the appliance.

This appliance is equipped with a three-prong (grounding) polarized plug for your protection against possible shock hazards.

Where a two-prong wall receptacle is encountered, contact a qualified electrician and have it replaced with a properly grounded three-prong receptacle in accordance with all local codes and ordinances.

## | ∕!\ WARNING! I

Electrocution hazard.

Electrical grounding required.

- Do not remove the round grounding prong from the plug.
- Do not use extension cords or ungrounded (two prong) adapters.
- Do not use a power cord that is frayed or damaged.
- Do not use a power strip.

Failure to follow these instructions may result in fire, electric shock or death.


## **Blocking for Safety**




To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.


## **PLANNING INFORMATION**

## **Appliance Dimensions**






MF 3051




MF 3651




Stated minimum height dimensions include when the levelled feet are fully inserted. Width will increase by 1/4" (6.5 mm) when mounting strips are installed.

## **Door Swing Clearance** (top view)

#### MF 1851



#### MF 2451



#### Inset installation style

A = 8 1/4" (210 mm) B = 1/2" (12.5 mm)

C = 19 7/8" (505 mm)

#### Frameless installation style

A = 8 1/2" (216 mm)

B = 1/2" (12.5 mm)

C = 20 3/8" (517 mm)

#### Inset installation style

A = 10 3/4" (273 mm)

B = 1/2" (12.5 mm)

C = 25 7/8" (658 mm)


#### Frameless installation style

A = 11'' (279 mm)


B = 1/2" (12.5 mm)

C = 26 3/8" (670 mm)

#### MF 3051



#### MF 3651



#### Inset installation style

 $A = 13 \, 1/4$ " (337 mm)

B = 1/2" (12.5 mm)

C = 31 7/8" (810 mm)

#### Frameless installation style

 $A = 13 \frac{1}{2}$ " (343 mm)

B = 1/2" (12.5 mm)

C = 32 3/8" (822 mm)

#### Inset installation style

A = 15 3/4" (400 mm)

B = 1/2" (12.5 mm)

C = 37 7/8" (962 mm)

#### Frameless installation style

A = 16" (406 mm)

B = 1/2" (12.5 mm)


C = 38 3/8" (975 mm)


Dimension A and B: Add panel thickness and handle to calculate distance to wall.

## **PLANNING INFORMATION**


### **Cabinet Opening Dimensions**


#### Continous toe kick





Individual toe kick





#### Δ

Cabinet depth frameless installation style = 25" (635 mm)

Cabinet depth inset installation style = 25" (635 mm) plus panel thickness

#### В

This is the point where the power cord exits from the appliance rear. 3/4" (19 mm) from the left and 5" (127 mm) from the floor.

Free length of the power cord is 98" (2.5 m).

#### **IMPORTANT**

The power plug must be easily accessible so that the appliance can be disconnected from the mains quickly in an emergency. It must not be behind the back of the appliance.

#### C

The appliance has a recess in this area for cable and waterline laying.

1" (25 mm) in depth and 5 1/2" (140 mm) in height over the whole width of the appliance.

#### D

This surface is visible when the appliance door is open. Designed finish is required.

#### 30" (762 mm) (762 mm) **D** D D D 3" (76 mm) (76 mm) (76 mm) (76 mm) (2134 mm) (2134 mm) 2 13/16" - 4 3/16" (72 - 106 mm) C' (102 mm) 36" 36" (914 mm) (914 mm) D **D** D D 3" 3" (76 mm) (76 mm) (76 mm) (76 mm) 84" (2134 mm) (2134 mm) 2 13/16" - 4 3/16" (72 - 106 mm) B B Ċ' (102 mm)

Continous toe kick

#### Δ

Individual toe kick

Cabinet depth frameless installation style = 25" (635 mm)

Cabinet depth inset installation style = 25" (635 mm) plus panel thickness

#### В

This is the point where the power cord exits from the appliance rear. 3/4" (19 mm) from the left and 5" (127 mm) from the floor.

Free length of the power cord is 98" (2.5 m).

#### **IMPORTANT**

The power plug must be easily accessible so that the appliance can be disconnected from the mains quickly in an emergency. It must not be behind the back of the appliance.

#### C

The appliance has a recess in this area for cable and waterline laying.


1" (25 mm) in depth and 5 1/2" (140 mm) in height over the whole width of the appliance.

#### D

This surface is visible when the appliance door is open. Designed finish is required.

## **PLANNING INFORMATION**

#### **Panel Dimensions**



#### 18" recess

#### Inset installation style

H = 79 7/8" (2029 mm)

 $W = 17 \ 3/4" \ (451 \ mm)$ 


#### Frameless installation style

H = 80" (2032 mm) plus overlapping of the panel on the top W = 18" (457 mm) plus overlapping of the panel on both sides

Minimum panel thickness = 5/8" (16 mm) \*

Maximum panel thickness = 1" (25 mm)

Maximum panel weight = 55 lbs (25 kg)



#### 24" recess

#### Inset installation style

H = 79 7/8" (2029 mm)

W = 23 3/4" (603 mm)


#### Frameless installation style

H = 80" (2032 mm) plus overlapping of the panel on the top W = 24" (610 mm) plus overlapping of the panel on both sides


Minimum panel thickness = 5/8" (16 mm) \*

Maximum panel thickness = 1" (25 mm)

Maximum panel weight = 66 lbs (30 kg)



\* If a "shaker style" panel is used which undershoots the minimum panel thickness, shorter screws than those supplied in the accessory pack must be used.a



#### 30" recess

#### Inset installation style

H = 79 7/8" (2029 mm)

W = 29 3/4" (756 mm)


#### Frameless installation style

H = 80" (2032 mm) plus overlapping of the panel on the top W = 30" (762 mm) plus overlapping of the panel on both sides

Minimum panel thickness = 5/8" (16 mm) \*

Maximum panel thickness = 1" (25 mm)

Maximum panel weight = 77 lbs (35 kg)



#### 36" recess

#### Inset installation style

H = 79 7/8" (2029 mm)

W = 35 3/4" (908 mm)


#### Frameless installation style

H = 80" (2032 mm) plus overlapping of the panel on the top W = 36" (914 mm) plus overlapping of the panel on both sides

Minimum panel thickness = 5/8" (16 mm) \*

Maximum panel thickness = 1" (25 mm)


Maximum panel weight = 88 lbs (40 kg)



\* If a "shaker style" panel is used which undershoots the minimum panel thickness, shorter screws than those supplied in the accessory pack must be used.a


### **Unpacking**

- 1. Cut the straps and remove them.
- 2. Press in the lug, tear or cut the carton on the edge and remove it.
- 3. Remove all styrofoam packing material from the sides and top.




4. Remove the box with mounting parts.

5. Remove the ventilation grille.



Risk of death or serious injury due to appliance tipping.


Do not remove the transit supports before the appliance is in the recess.



**WARNING!** 

Risk of injury and damage.


Four people are required to safely remove the appliance from the bottom pallet.




One person removes the pallet.
Place the appliance carefully on the floor.


### Alternative possibility:

Cut off the marked area from the pallet.






Tilt the appliance slightly sideways.



Slide a two-wheeled cart between the appliance and packaging.


Restrain the appliance to the cart with straps.

Tilt the appliance onto the cart.



Place the appliance carefully on the floor.

## STANDARD ACCESSORIES



### **Anti-tipping device**

Secure the appliance in place so it does not tip forward when the fully stocked door is opened. The anti-tipping bracket is provided with the appliance.

- May only be installed by trained personnel.
- The (1/4" x 2-3/8") screws are designed for standard dry walls.
- If the anti-tipping bracket cannot be secured properly using the (1/4" x 2-3/8") screws, use suitable anchors or different screws.

#### Position anti-tipping device - Figure 1-2

#### **IMPORTANT**


Cabinet depth min. 25"

The anti-tipping bracket will be fastened to the floor downwards and to the spacer backwards.



Be sure the wooden spacer is fastened securely to the floor.

#### Inset kitchen cabinets - Figure 1



#### Frameless kitchen cabinets - Figure 2




Figure 2

#### **IMPORTANT**

If the floor slopes down sideways, the anti-tipping bracket must be fitted horizontally. Lay down spacers in the appropriate positions.

## Mounting the anti-tipping device on wooden floors - Figure 3

1. Mark the center line of the appliance on the back wall. Align the anti-tipping bracket center to this line.

## ■ <u></u> WARNING!

Be sure that there is no plumbing or electrical wiring located in this area which screws or drills could damage.

- 2. Fasten bracket to the wooden floor using 5 screws (1/4" x 2-3/8"). Drill pilot holes if necessary.
- 3. Fasten bracket with 3 screws (1/4" x 2-3/8") into the wall plate.




Figure 3



Screw length measuring tool

## Mounting the anti-tipping device on concrete floors - Figure 4 - 5

1. Mark the center line of the appliance on the back wall. Align the anti-tipping bracket center to this line.

## I <u>∕!</u>\ WARNING! ■

Be sure that there is no plumbing or electrical wiring located in this area which screws or drills could damage.

2. Drill a 3/8" diameter hole in any position as shown in **Figure 4** using a carbide drill bit.

The depth of the holes must exceed the overall length of the anchors.

Clean the holes after drilling.

3. Attach washer and screw on hex nut to the end of each anchor.

Drive in all 3 anchors.

Align the bracket center to the center line on the back wall again.

Fasten the anchors by turning the hex nut.

4. Fasten bracket with 3 screws (1/4" x 2-3/8") into the wall plate (Figure 5).




Figure 5

Wall Plate

## Safety Instructions and Warnings for Water Connection

- Do not install the water connection while the appliance is connected to an electrical outlet.
- The connection to the water supply may only be made by a trained and licensed plumber.



Connect to potable water supply only.

## **Water Connection Requirements**

 The water pressure must be in the range of 40-90 psi (2.8-6.2 bar).


Failure to meet these requirements may result in ice maker malfunction and a water leak that can damage flooring and surrounding furniture.

 A shut-off valve must be installed between the water line and the main water supply. It must be easily accessible so the water supply can be stopped immediately if necessary.


#### **IMPORTANT**

Do not install the shut-off valve behind the appliance.

For the water supply we recommend braided style ice maker hoses with 1/4" connectors.



To connect to a 1/4" copper line use a 1/4" compression nut and a metal compression ring.



To connect to a 1/4" PEX line use a 1/4" compression nut and a plastic compression ring.


A water line is not supplied with the appliance.


#### **IMPORTANT**

Do not use any old or already premounted water supply lines.

### **Appliance Installation**


Move the appliance towards the final position and leave enough space to work behind.






#### **IMPORTANT**


Make sure that the connection is fitted with a seal and is tight.





The steel plate can be removed to facilitate connecting the water hose.





## **INSTALLATION**














Apply the appliance cover strips to the left and right front edge of the appliance housing, align in height with the top profile and screw into place. The strip is transparent so the designed mounting holes on the appliance housing are visible. We recommend that you mark and predrill the hole positions in the strip.






#### **IMPORTANT**

Use the correct flat head screws, otherwise the edges of the cabinet will be damaged when sliding the appliance into the recess.





Recess Top view Slide the appliance into the recess. To avoid damage, move the power cord and the water line at once.

Align the appliance in depth.

X = Recess front to appliance housing front (not cover strip)

Inset 7/8" (22 mm) panel X = 25/8" (66 mm)

Inset 3/4" (19 mm) panel  $X = 2 \frac{1}{2}$ " (63 mm)


Inset 5/8" (16 mm) panel X = 2 3/8" (60 mm)


#### **Frameless**

 $X = 1 \frac{3}{4}$ " (44 mm)

or

with the depth adjustment aid: The surface of the depth adjustment aid must be flush with the surface of the recess. (Example shows 3/4" (19mm))








Risk of death or serious injury due to appliance tipping.

Do not open the appliance door before the height adjustment is finished and the antitipping bracket supports the appliance.



Turn clockwise to raise the appliance.

Raise the appliance evenly by turning the screws successively until the appliance back touches the anti-tipping bracket (lift approx. 1/4" / 6.5 mm).

To attain the minimum base panel height of 4" (102 mm), the adjustable feet must be raised by 1/4" (6 mm) to 5/16" (8 mm).


Maximum height adjustment of the appliance = 3/4" (19 mm)

#### **IMPORTANT**


When turning the screws with a power driver please consider absolutely.

Maximum rotation speed = 400 rpm Maximum torque = 8.8 lbs/in (1 Nm)

Failure to follow this instruction will result in damage to the height adjustment unit.




Remove the depth adjustment aid before fastening the appliance in the recess.





Tx™ 15


Fasten the appliance in the recess through the appliance cover strips using eight screws 4 x 14 for each side. We recommend that you mark and pre-drill the hole positions in the strip.



Close the front part of the appliance cover strips.


#### Hint:

Use the removed transportation safety component to help with closing.





Push the mounting strip upwards. The bottom edge of the mounting strip must be aligned with the top edge of the adjacent cabinet door.


#### Inset installation style



#### Frameless installation style








Risk of damaging the panel. Do not undershoot the minimum panel thickness (shaker style).

#### **IMPORTANT**

Door handles should be mounted now because the side support strips will cover the mounting holes.



Only use countersunk screws for handle mounting.

The holes should be countersunk.

The screw heads should be flush with the panel.

Position the panel support strips with the top lug in the cut of the top attachment bracket. Align the strips parallel to the side edge of the panel and screw into place with ten 4 x 14 screws. 4 mm Tx™ 15 **IMPORTANT** 73 5/8" (1870 mm) Risk of damaging the panel. Do not undershoot the minimum panel thickness (shaker style). 1/8" (3 mm) 1/8" (3 mm) or Tx™ 15


> Mount the base of the ventilation ductdivider with two screws 4 x 19.

Click on the cover.


#### **IMPORTANT**

If the door has to be limited to a 90° opening angle, it must be done before the panel is mounted onto the appliance door. See chapter "Important Note for Changing over Door Hinges or Limiting the Hinges to a 90° Opening Angle" on page 24.

Open the appliance door.




Close the door and check the position of the panel.




#### **IMPORTANT**

After a certain time and loading, it may be necessary to readjust the door again.




Maximum adjustment: 15 mm (5/8")



Align the panel horizontally with the long holes in the attachment bracket.

Tighten the hex nuts.




Align the panel in its depth.


Loosen the screws, align the panel and tighten the screws.

Align the panel in its depth at the bottom.

Loosen the screws, align the panel and tighten the screws. Use the Torx 20 key provided.



Fasten the panel through the bottom attachment bracket with two screws 4 x 14.




#### **IMPORTANT**

Risk of damaging the panel. Do not undershoot the minimum panel thickness (shaker style). Insert the panel supports into the support strips between panel and appliance door and screw into place with two screws M6 x 12 each.




Hook the door cover strips at the front of the supports and snap in at the back.






Adjust the brackets to the thickness of the toe kick panel.




Remove the backing foil and affix the toe kick panel.




Check that there is no gap between the appliance air divider and the door air divider.

#### **IMPORTANT**

There will be a gap if the ventilation grille is fitted incorrectly.






## SmartDeviceBox (Not Supplied in All Countries)

Download the "SmartDevice App" to your smartphone.

Start the app on your smartphone and follow the instructions.






## Please note in case of removing appliance from the recess

If the appliance has to be removed from the recess again, please make sure you take account of the following.

- 1. Unload the appliance.
- 2. Disconnect the appliance from the power source.
- 3. Remove the mounted front panel from the appliance door.
- 4. Lower the appliance using the height adjustment unit.



## 

Risk of death or serious injury due to appliance tipping.

Do not remove the appliance without the mounted transit supports.

# Important Note for Changing over Door Hinges or Limiting the Hinges to a 90° Opening Angle

Changing the door hinges or limiting the hinges to a  $90^{\circ}$  opening angle should only be carried out by a trained expert.

The door hinges are fitted with strong closing springs. If the hinge accidentally snaps shut, this can lead to serious injury.

The door itself is very heavy. Do not try to dismount the door yourself.

Contact the Liebherr service for more information. See contact details on the back of this manual.

#### For Service in the U.S.

#### **Liebherr Service Center**

Toll Free: 1-866-LIEBHER or 1-866-543-2437

Email: Service-appliances.us@liebherr.com

PlusOne Solutions, Inc.

3501 Quadrangle Blvd, Suite 120

Orlando, FL 32817

#### For Service in Canada

#### **Liebherr Service Center**

Toll Free: 1-888-LIEBHER or 1-888-543-2437

www.euro-parts.ca

#### **EURO-PARTS CANADA**

39822 Belgrave Road Belgrave, Ontario, N0G 1E0

Phone: (519) 357-3320 Fax: (519) 357-1326







www.liebherr-appliances.com